

Operating limits

- Although the weighing platforms have an extremely rugged construction, the load limits shown in the following tables should not be exceeded.
- Depending on the type of loading, the maximum safe static load, i.e. maximum admissible loading is:



- With central load DUCS...s 1000 kg 1750 kg DUE...s / DUF...s DU...painted 1750 kg
- With side load DUCS...s 600 kg 900 kg DUE...s/ DUF...s DU...painted 900 kg
- With one-side cornerload 300 kg DUCS...s DUE...s / DUF...s 450 kg DU...painted 450 kg
- With single wheel load 200 kg DUCS...s DUE...s / DUF...s 400 kg DU...painted 400 ka




Falling loads, shocks and lateral impacts must be avoided.

- approach ramps are passive, i.e. in the weighing operation all wheels of the conveying vehicle must be on the load plate.
- The air gap between load plate and the approach ramps must be free. It is thus essential, particularly when weighing granular or small-sized weighing samples, to check the gap at regular intervals and keep it free.

Cleaning the weighing platform

Maintenance of the weighing platform is restricted to regular cleaning. The procedure depends on not only the type of surface, but also the ambient conditions prevailing at the location.

Cleaning the exterior of the painted weighing platforms in dry surroundings



 Wipe with a damp cloth, usual house hold cleaning agents.

Cleaning agents


• Use disinfectants and cleaning agents only in accordance with the producer's instructions.

Cleaning the exterior of the stainless steel weighing platforms in wet surroundings

- Water iet.
- Usual household cleaning agents.


Cleaning the exterior of the stainless steel weighing platforms in corrosive surroundings

- It is essential to remove corrosion initiating substances at regular intervals.
- Use disinfectants and cleaning agents only in accordance with the producer's instructions and stipulations.
- Water jet up to 60 °C.
- Possibly after-treatment with OKS 371 universal oil.



The load plate of the weighing platform is the active weighing component, the

7. Optional equipment



Approach	ramps	Order-No.
Approuch	Iuiiipo	Oluci-ito.

Painted version

 Lenght 300 mm :
 22003526

 CS 850 mm
 22003527

 E 1250 mm
 22003527

 F 850-1250 mm
 22003533

Stainless steel version

Foot plate set

Painted version with horizontal stop 22003532

Stainless steel version with horizontal stop

00507089

2. Equipotential bonding

The equipotential bonding must be installed by a professional electrician when unsing the weighing platform in Zones 1/2 and 21/22. METTLER TOLEDO Service only has a monitoring and consulting here.

=> Connect equipotential bonding (PA) of all devices (weighing platform and service terminal) in accordance with the country-specific regulations and standards. In the process, make sure that all device housings are connected to the same potential via the PA terminals.

3. Putting into operation

All operating terminals with IDNet interface can be attached to the DU weighing platforms. The weighing platforms of the T-version can be attached to operating terminals with integrated A/D converter.

Terminal	Color
EXC+ (IN+)	grey
SEN+ (IN-)	yellow
SIG+ (OUT+)	with
SIG- (OUT-)	brown
SEN-	green
EXC-	blue

Connecting analog (T) version

4. Technical data DU (stainless steel)

4.1 Load cell

Ignition protection type: II 2G EEx ia IIC T6...T4
-20°C ≤ Ta +40°C

II 2D IP68/66 T 70°C

4.2 Electronic housing Point ADC Point Ex

Ignition protection type: II 3G Ex nA II T4; Ex nV II T4

TÜV Nord TÜV 99 ATEX 1445 II 2G EEx ia IIC T4 II 2D IP68 T 75°C II 3G/D EEX nA II T4 $-20^{\circ}\text{C} \leq \text{Ta} \leq +60^{\circ}\text{C}$

BVS 03 ATEX E 432

T+50°C IP68 ASEV 00 EX 0494

Analog (T)
passive component

1. Cautionary notes


DU-line (painted)

• Never operate in hazardous areas!

DU-line (stainless steel)

• The explosion-protected weighing platform is approved for operation in hazardous areas (see technical data).

There is an increased danger of injuries and demage when using the weighing platform in hazardous areas! Exercise particular care when using in such areas. The rules for behavior are based on the concept of "Safe Distribution" established by METTLER TOLEDO.



Selection of the location

- The foundation at the installation site must be capable of safely supporting the weight of the scale at the support points when it carries the maximum load. At the same time, it should be so stable that no vibrations occur during weighing operations. These requirements also apply if the weighing platform is integrated in conveying systems and the like.
- Ensure the vibrations due to machines near the installation site are kept to a minimum


Ambient conditions for the DU-line (painted)

• Use weighing platform only in a dry environment.

Ambient conditions for the DU-line (stainless steel)

• Weighing platform can be used in a dry or wet environment.

Using DU...x-platforms in hazardous areas, please note additionally the operating instructions "Explosion proof Weighing system 00704516".



ID-Net version

Order-No.

Connection cable extension, length 10 m, connectors at both ends, for remote location of terminal

00504134

Cable adapter kit, comprising two junction boxes for extending connection cable up to 100 m. Box at terminal end with connection cable of length 2.5 m.

00504133

Special cable on reel, used with cable adapter kit for extension of connection cable to required lenght.

00504177

Analog version


Connection cable analog, length 10 m, both ends prepared for remote location of the terminal with integrated A/D converter.

00204555

Operating instructions

METTLER TOLEDO MultiRange Low profile scales DU line







00705990

Subject of technical changes © Mettler-Toledo (Albstadt) GmbH 04/04 Printed in Germany 00705990J

Mettler-Toledo (Albstadt) GmbH

D-72458 Albstadt

Tel. ++49-7431-14 0, Fax ++49-7431-14 232

Internet: http://www.mt.com

