



English **Operating Instructions**

METTLER TOLEDO

Line of JL balances



- **JL-G Gold balances**
- **JL-C Carat balances**




www.mt.com/jewelry

METTLER TOLEDO


Operating instructions in a nutshell

 Press key **briefly**
 Press and **hold key down** until the desired display appears
 ▼ automatic sequence
 * These functions must be activated in the menu (section 4.3.2).


Switching on




Switching off




Simple weighing




Adjusting (calibration) external




Taring




Piece counting*



Percent weighing*



Free factor / selectable display increment*



Contents


1	Getting to know your balance	4	5	Functions	22
1.1	Introducing the JL balance line	4	5.1	Piece counting	22
1.2	Layout of balances	5	5.2	Percent weighing	23
1.3	Overview of key functions	6	5.3	Switching weight units	24
2	Startup	7	5.4	Weighing with free factor and/or selectable display increments	24
2.1	Unpacking / standard equipment	7	6	Technical data, options, optional equipment	26
2.2	Setting up, leveling, preparations for weighing below the balance	8	6.1	Technical data	26
2.3	Cautionary notes / Power supply	9	6.2	Options	29
3	Weighing	12	6.3	MT-SICS Interface commands and functions	29
3.1	On/off switching	12	6.4	Optional equipment	31
3.2	Simple weighing	12	6.5	Dimensional drawings	32
3.3	Faster weighing with reduced readability	13	7	Appendix	34
3.4	Taring	13	7.1	Typical printouts from METTLER TOLEDO RS-P26 and LC-P45 printers	34
4	Menu	14	7.2	What if...?	35
4.1	Overview	14	7.3	Maintenance and cleaning	36
4.2	Menu operation	15	7.4	Declaration of conformity	37
4.3	Description of menu options	16			

1 Getting to know your balance


Thank you for choosing a METTLER TOLEDO balance.

1.1 Introducing the JL balance line

JL-G




JL-C





Balance features

- The JL balance line ranges from high-resolution carat balances (JL-C) with a readability of 0.001 ct through 0.01 ct to gold balances (JL-G) with a readability of 0.01 g to 0.1 g. The weighing ranges extend from 122 g to 7.1 kg.
- The operation of all these balances is identical.
- In addition to basic operations such as **weighing**, **taring** and **adjusting** (calibration) miscellaneous functions such as "**Piece counting**", "**Percent weighing**" or "**Free factor**" can be activated.
- JL-C balances are fitted with a glass draft shield in the factory; with other models a draft shield is available as an optional extra.



Note

All models are available as certified versions. Please ask your METTLER TOLEDO dealer for details.



1.2 Layout of balances

- 1 Keys
- 2 Display with backlight
- 3 Model plate with the following data:
 - "Max": maximum capacity
 - "d": readability
 - "Min": minimum capacity (recommended minimum load; **only relevant for certified balances**)
 - "e": verification scale interval (smallest display increment tested during certification; **only relevant for certified balances**)
- 4 Draft shield element (only for JL-C models)
- 5 Weighing pan
- 6 Draft shield (supplied as standard with all JL-C models)
- 7 Leveling feet
- 8 Hanger opening for weighing below the balance (underside of balance)
- 9 AC adapter socket
- 10 Optional RS232C interface
- 11 Lug for optional antitheft device
- 12 Leveling control
- 13 Compartment for batteries (for all JL-G, JL503-C5 and JL502-C models)
- 14 Optional RS232C interface with mini-DIN connector (only certified models)

1.3 Overview of key functions





Weighing mode








Menu





The balances have two operator control levels: the **weighing mode** and the **menu**. The function of each individual key depends on the operator control level and how long the key is pressed.

Key functions in weighing mode	
Press briefly 	Press and hold down 
1/10d • Reduce readability	Cal • Adjust (calibrate)
On • Switch on →0/T← • Zero/tare C • Cancel function	Off • Switch off
 • Switch • Change settings	F • Call function; A function must be activated in the menu, otherwise "F nonE" appears in the display
 • Transfer weighing data via interface with activated printer • Confirm settings	Menu • Show menu (hold key down until MENU appears)

Key functions in menu mode	
Press briefly 	Press and hold down 
1/10d • Change settings • Reduce value by 1 step	1/10d • Reduce value rapidly
C • Close menu (without saving changes)	—
 • Change settings • Increase value by 1 step	 • Increase value rapidly
 • Select next menu item	Menu • Save changes and close menu

2 Startup

2.1 Unpacking / standard equipment







The standard equipment for every balance comprises:

- **AC adapter**, to national standard
- **Weighing pan** (+ **Weighing pan support** for JL-G, JL503-C5 and JL502-C models)
- **Draft shield element** (only for JLxx3-C models)
- **Draft shield** (only for JL-C models)
- **Protective cover** (placed on the balance over the weighing cell cone) with instruction sheet. **This protective cover must not be mislaid. It will be needed again later to protect the cone when changing batteries (underside of balance).**
- **In-use cover**
- **Operating instructions**
- **Carat pan** (only for JL-C models)
- **Adjustment weight** (only for JL-C models)

In the case of models having the large weighing pan (\varnothing 160 mm), the antistatic plate **a)** (secured by two screws) and the adapter ring **b)** must also be removed in order to fit the in-use cover.

In the case of models having the draft shield, the antistatic plate **a)** (secured by two screws) and the draft shield **c)** must also be removed in order to fit the in-use cover.

2.2 Setting up, leveling, preparations for weighing below the balance



The optimum location


The correct location makes an important contribution to the accuracy of the weighing results of high-resolution balances.

- Stable, vibration-free position as horizontal as possible
- No direct sunlight
- No excessive temperature fluctuations
- No drafts

The best location is on a stable bench in a corner protected against drafts, as far away as possible from doors, windows, radiators or the louvers of air conditioners.

Leveling

All models are equipped with a level glass and two or four leveling feet to compensate for minor irregularities in the surface on which the balance stands. The balance is exactly horizontal when the air bubble is in the middle of the level glass.



Note: The balance should be leveled each time it is moved to a new location.

Antitheft device

Models in the JL-C/JL-G balance line are provided with a lug for attaching an antitheft device (see optional equipment in Section 6.4).


Preparations for weighing below the balance

To carry out weighing operations below the balance, get rid of the special cover on the underside of the balance. This exposes the opening for the hanger, making weighing below the balance possible.



Note: Never put the balance without the protective cover over its cone down on its head, only on its side!

2.3 Cautionary notes / Power supply



2.3.1 Power supply

- JL-C/JL-G balances **must not be operated in hazardous areas** with the standard-supply AC adapter.
- Before connecting the AC adapter, verify that the voltage printed on it corresponds to the local AC power supply voltage. If this is not the case, please contact your local METTLER TOLEDO dealer.
- Only use these balances in a dry environment.
- For use with an certified (CSA or equivalent) power supply, which must have a limited and SELV circuit output.

Power supply

- Plug the AC adapter into the AC adapter socket on the balance, and connect to the power supply. The balance performs a self-test. This test is finished when "OFF" appears.
- Press the «On» key briefly: the balance is in operational readiness. Before any work is performed with the balance, it must be adjusted (Section 2.4).


2.3.2 Battery operation

All JL-G, JL503-C5 and JL502-C models can also be operated independently of the AC power supply by using their batteries. **To do this, always fit the protective cover over the weighing cell cone first**, then open the cover of the battery compartment on the underside of the balance and insert the batteries.



Caution: Ensure correct polarity (as specified inside the battery compartment).

Close battery compartment again.



When the balance is operating on its batteries, the border around the battery symbol in the display lights up. The number of segments that are lit is an indicator of battery condition (3 = fully charged, 0 = discharged). When the batteries are almost completely discharged, the last segment flashes.

Recommended battery type: AA (LR6) 1.5 V alkali-manganese.

NiMH (nickel-metal hydride) rechargeable batteries, which are recharged in an external battery charger, can be also be used. The intervals between recharging are not as long as the service life of a nonrechargeable battery.

Notes


- Batteries are not included in the standard supply.
- Battery operation is automatically overridden when the AC adapter is connected to the AC power supply.
- To prolong battery (disposable or rechargeable) life, it is advisable to activate «Auto shut off» in the menu
 - balance (see Section 4.3.7).
 - backlight (see Section 4.3.8).
- All discharged batteries must be disposed of in an environmentally responsible manner. No attempt must be made to incinerate or disassemble them.

2.4 Adjusting (calibration)

To obtain accurate weighing results, the balance must be adjusted to match the gravitational acceleration at its location.

Adjusting is necessary

- before the balance is used for the first time
- at regular intervals during weighing service
- after a change of location



To obtain accurate results, the balance must be left switched on for 60 minutes to reach operating temperature before starting the adjustment procedure.

- Have required adjusting weight ready.
- Unload weighing pan.
- Press and hold the «Cal» key down until "CAL" appears in the display. Release key. The required adjustment weight value flashes in the display.
- Place adjustment weight in centre of pan. The balance adjusts itself auto-matically.
- When "0.00 g" flashes, remove adjustment weight.


The adjusting is finished when the message "CAL done" appears briefly in the display, followed by "0.00 g". The balance is again in weighing mode and ready for operation.

Notes

- **Certified models cannot be adjusted by the user**, because of weights and measures legislation. This must be done by a METTLER TOLEDO service technician or a weights and measures inspector.
- This adjustment procedure can be terminated at any time with the «C» ("Cancel") key. The balance reverts to weighing mode.


3 Weighing

3.1 On/off switching



Switching on


- Remove any load from weighing pan and press «**On**» key briefly.
The balance performs a display test (all segments in the display light up briefly).
When zero is displayed, the balance is ready for operation.



Switching off


- Press and hold the «**Off**» key down until "OFF" appears in the display. Release the key.

3.2 Simple weighing



- Place weighing sample on the weighing pan.
- Wait until the stability detector "o" disappears.
- Read the result.


3.3 Faster weighing with reduced readability




The balance has the facility for speeding up the weighing operation by reducing its readability (number of decimal places):

- The balance is operating with its **normal readability and speed**.
- Press the «**1/10d**» key and ...
- ... the balance operates with **reduced readability** (one decimal place less), but displays the weighing result quicker. Pressing the «**1/10d**» key briefly again toggles the balance back to its full readability.


3.4 Taring





- Place empty container on the balance.





- The weight is displayed.



- Press the «**→0/T←**» key briefly.



- Add weighing sample to container. The net weight is now displayed.



If the container is removed from the balance, the tare weight will be shown as a negative value. The tare weight remains stored until the «**→0/T←**» key is pressed again or the balance is switched off.

4 Menu


4.1 Overview

In the menu you can change the weighing unit (for certified balances, only if national weights and measures legislation allows), select additional functions and carry out various settings. A description of the individual menu options is given in Section 4.3.

Notes






- 1) With certified balances, this menu option has a fixed setting and cannot be changed.
- 2) Factory setting: JL-G: g
JL-C: ct
- 3) With certified balances, only those weighing units allowed by the appropriate national weights and measures legislation may be selected.
- 4) This menu option is only shown if "Host" has been selected in menu option 9 (Peripheral unit).
- 5) This menu option is only shown if "S.oFF" has not been selected in menu option 10 (Send mode).
- 6) These menu options are only shown if "Host" or "Printer" has been selected in menu option 9 (Peripheral unit).
- 7) Only displayed if the optional interface has been installed.

Overview of menu



Menu option
Factory setting

4.2 Menu operation



Opening the menu

In weighing mode, press and hold down the «**Menu**» key until "MENU" appears in the display. Release the key: the 1st menu option is displayed.

Select menu options

The «**↔**» key is used to select individual menu options with their current settings one after the other.

Change settings

Pressing the «**↶**» key displays the next setting; pressing the «**1/10d**» key displays the previous one. Once the desired setting appears in the display, the next menu option can be selected («**↔**») or you can close the menu (see following Section).

Saving settings and closing the menu

Hold the «**Menu**» key down until "StorEd" appears in the display. Release the key and the balance reverts to weighing mode. All changes are saved.



Abort

Press the «**C**» key briefly. The balance reverts to weighing mode. Changes are **not** saved.

Note

If no entry is made within 45 seconds, the balance reverts to weighing mode. Changes are **not** saved.

4.3 Description of menu options



4.3.1 Reset or recording of balance settings (1st menu option "RESET")

Reset balance settings


→ Select "Reset", press and hold down the «**Menu**» key until the message "r donE" confirms that all menu settings have been reset. The balance then reverts to weighing mode and works with the factory settings (Section 4.1).

Recording balance settings

→ Select "List" and hold down the «**Menu**» key until the message "StorEd" is displayed.

The current balance settings are transmitted to the peripheral device connected to the optional RS232C interface. To do this the setting "Printer" must always be selected at the 9th menu option (Peripheral unit). The current balance settings are saved at the same time.

4.3.2 Functions (2nd menu option / see Section 5 for their use)

In addition to simple weighing, the following functions can be selected with the «» key:

F nonE	No function, simple weighing
F count	Piece counting
F 100 %	Percent weighing
F FAC M	Multiply free factor value by weight, change size of display increment
F FAC d	Divide free factor value by weight, change size of display increment



Std

doS

robuSt

4.3.3 Weighing mode (3rd menu option)

This setting allows you to adapt the balance to the weighing mode. Select "Std" (standard) for all normal weighing processes. With "doS" (dosing) - for dispensing substances in liquid or powder form - the balance reacts very rapidly to the slightest changes of weight. With "robuSt" (absolute weighing) the balance only reacts to more significant changes in weight, so that the weighing result is very stable.



Unit | g

Unit | kg

⋮

4.3.4 Weighing unit 1 (4th menu option "UNIT 1")

Depending on requirements, the balance can operate with the following units (possible with certified balances only if permitted by national weights and measures legislation):

Unit	Conversion factor	Comments
g gram		
kg kilogram	1 kg = 1000 g	not with 0.1 mg and 1 mg balances
mg milligram	1 mg = 0.001 g	with 0.1 mg and 1 mg balances
ct carat	1 ct = 0.2 g	
lb pound	1 lb = 453.59237 g	
oz ounce	1 oz = 28.349523125 g	
ozt troy ounce	1 ozt = 31.1034768 g	
GN grain	1 GN = 0.06479891 g	not with 1 g balances
dwt pennyweight	1 dwt = 1.55517384 g	
mo momme	1 mom = 3.75 g	
m Mesghal	1 msg ≈ 4.6083 g	
H tl Hong Kong tael	1 tlh = 37.429 g	
S tl Singapore tael	1 tls ≈ 37.7993641666667 g	The Malaysian tael has the same value
t tl Taiwan tael	1 tft = 37.5 g	
cl tical	1 tical ≈ 16.3293 g	
t o tola	1 tola = 11.6638038 g	
b t baht	1 baht = 15.16 g	




Unit | oz

⋮



Unit | dwt

4.3.5 Weighing unit 2 (5th menu option "UNIT 2")

If it is required to show the weighing result in weighing mode in an additional unit by pressing the «» key, the desired second weighing unit can be selected in this menu option. The same weighing units are available as under "UNIT 1", with the exception of the tael units ("H tl", "S tl" and "t tl").

4.3.6 Autozero (6th menu option / see overview and notes in Section 4.1)

This menu option allows you to switch the automatic zero correction on or off.

Autozero switched on

The zero point is automatically corrected (e.g. if drift occurs or the weighing pan becomes dirty). Certified balances, however, have a fixed zero point.

Autozero switched off

The zero point is not automatically corrected. This setting is advantageous for special applications (e.g. evaporation measurements).



RZEro

no RZEro

4.3.7 Auto shut off (7th menu option)

If the automatic shut off function is activated, the balance automatically switches itself off after a selected period of inactivity (i.e. with no key being pressed or changes of weight occurring):

A.OFF 10' Automatic shutoff after 10 minutes inactivity

A.OFF - Automatic shutoff **not** activated

A.OFF 30'' Automatic shutoff after 30 seconds inactivity

A.OFF 2' Automatic shutoff after 2 minutes inactivity

A.OFF 5' Automatic shutoff after 5 minutes inactivity



A.OFF 10'

A.OFF -

A.OFF 30''

A.OFF 2'

A.OFF 5'



bL 30''
bL 1'
bL 2'
bL 5'
bL On
bL oFF

4.3.8 Backlight (8th menu option)

Under this menu option, the backlight can be switched on or off. If the automatic switch-off is activated, the backlight will turn off automatically after the selected period of inactivity has elapsed. The backlight is reactivated when a key is pushed or the weight is changed.

Note: The backlight of the PL-S auxiliary display is not affected by this function.

b.L 30''	Automatic switch-off after 30 sec. inactivity
b.L 1'	Automatic switch-off after 1 min. inactivity
b.L 2'	Automatic switch-off after 2 min. inactivity
b.L 5'	Automatic switch-off after 5 min. inactivity
b.L On	Backlight is always on
b.L oFF	Backlight is switched off



Pr intEr
HoSt
2d ISPLAY

4.3.9 Peripheral unit (9th menu option / see overview and notes in Section 4.1)

Peripheral devices can only be connected if the balance has been equipped with the optional RS232C interface. The balance automatically saves the appropriate settings (Sections 4.3.10 – 4.3.14) for every peripheral device.

Printer	Connected to a printer.
Host	Connection to any desired peripheral device.
Aux. display	Connection of an optional auxiliary display unit (communications parameters cannot be selected).



S.oFF
S.Stb
S.Cont
S.Auto
S.All

4.3.10 Send mode (10th menu option / see overview and notes in Section 4.1)

Note: This menu option is only available if the "Host" setting was selected in the 9th menu option (Peripheral unit)!

It specifies how a value is transferred to a peripheral device.

S.oFF	Send mode switched off.
S.Stb	The next possible stable value will be transferred after the « \square » key has been pressed.
S.Cont	All values are transferred automatically.
S.Auto	Only stable values are transferred automatically.
S.All	The current value is transferred after the « \square » key has been pressed.

4.3.11 Send format (11th menu option / see overview and notes in Section 4.1)

Note: This menu option is only available if the "S.oFF" setting was **not** selected in the 9th menu option ("Send mode")! It sets the data transfer format.

"S. SICS": The MT-SICS data transfer formats are used. Please refer to the "Reference Manual MT-SICS 11780447", downloaded from the Internet (www.mt.com/sics-classic). More Information please find in the Section 6.3.

"S. PM"*: The following PM balance data transfer formats are used:

S.Stb: `▯▯▯▯▯▯1.67890/g`

S.Cont: `S▯▯▯▯▯1.67890/g SD▯▯▯▯▯1.39110/g`

S.Auto: `S▯▯▯▯▯1.67890/g`

S.All: `▯▯▯▯▯▯1.67890/g`

`▯D▯▯▯▯▯1.39110/g`

* unidirectional, no MT-SICS commands are accepted.



S. SICS

S. PM*

4.3.12 Baud rate (12th menu option / see overview and notes in Section 4.1)

Note: This menu option is only available if the "Printer" or "Host" setting was selected in the 9th menu option (Peripheral unit)!

The baud rate (data transfer rate) determines the speed of transmission via the serial interface. The unit is the baud (bd) = 1 bit/second.

The following settings are available: 600 bd, 1200 bd, 2400 bd, 4800 bd, 9600 bd and 19200 bd.

For problem-free data transmission the sending and receiving devices must be set at the same value.



bd 2400

bd 4800

⋮



bd 19200



7b-E

7b-no

8b-no

7b-odd

4.3.13 Bit/Parity (13th menu option / see overview and notes in Section 4.1)

Note: This menu option is only available if the "Printer" or "Host" setting was selected in the 9th menu option (Peripheral unit)!

It sets the character format for the peripheral device connected to the balance.

7b-E 7 data bits/even parity

7b-no 7 data bits/no parity

8b-no 8 data bits/no parity

7b-odd 7 data bits/odd parity



HS oFF

HS SoFt

HS HARd

4.3.14 Handshake (14th menu option / see overview and notes in Section 4.1)

Note: This menu option is only available if the "Printer" or "Host" setting was selected in the 9th menu option (Peripheral unit)!

This function is used to select the data transfer mode to suit different serial devices.

HS oFF No handshake


HS SoFt Software handshake (XON/XOFF)

HS HARd Hardware handshake (RTS/CTS)

5 Functions

Settings and values saved under a given function are retained until they are replaced or another function is selected. The «C» key can be used to cancel the procedure currently in progress.

5.1 Piece counting



Requirement

The function "F count" must be activated in the menu (Section 4).

→ Place empty container on the balance and tare by briefly pressing the «→0/T←» key.

Setting the reference: a reference weight must first be entered for piece counting:

→ Add a number of reference pieces to container. Possible numbers are 5, 10, 20, 50, 100 and "no" (piece counting deactivates).

Note that the minimum weight = 10d (d: display increment), and the minimum unit weight = 1d!

→ Hold the «F» key down until "SEt ... PCS" is displayed.

→ Repeatedly press the «↶» key until the display equals the number of reference pieces entered.

→ Confirm the number of reference pieces with the «↷» key or automatic acceptance after 7 seconds. The current number of pieces (PCS = pieces) is displayed.

Switching between piece count and weight display

→ Place the items to be counted in the container. The number of pieces is displayed.

→ Press the «↶» key. The weight is displayed (in unit 1, and if the key is pressed again, in unit 2, provided this function is activated).

→ Return to the piece count display by pressing the «↶» key again.

5.2 Percent weighing



0.00 g

14850 g

SEt 100 %

100.00 %



10 1.60 %

150.88 g

10 1.60 %

Requirement

The function "F 100 %" must be activated in the menu (Section 4).

Set target weight

- Target weight (Reference weight, which corresponds to 100 %) in centre of pan. Note that the minimum weight = 10d (d: display increment).
- Hold the «F» key down until "SEt 100 %" is displayed.
- Press the «G» key to select "SEt 100 %" or "SEt no %" (Percent weighing deactivated).
- The «E» key can be used briefly to confirm or automatic acceptance after 7 seconds.

Switching between percent weighing and weight display

- Place weighing sample in centre of pan.
The weight of the sample is displayed as a percentage of the target weight.
- Press the «G» key. The weight is displayed (in unit 1, and if the key is pressed again, in unit 2, provided this function is activated).
- Return to display in percent: pressing the «G» key again.

5.3 Switching weight units


Requirement

Different weight units must be activated in the menu for unit 1 and unit 2 (Section 4).



64.71 g

64710 mg

→ The «» key can be used at any time to toggle between the two weighing units selected in the menu ("UNIT 1" and "UNIT 2").

Note

- Switching between weight units may be blocked with **certified balances**, depending on national weights and measures legislation.

5.4 Weighing with free factor and/or selectable display increments

In this menu option a custom "free factor" can be defined at will.


This value is then either multiplied ("F FAC M") by the weighing result (in grams), i.e. $\text{reading} = \text{factor} * \text{weight}$, or it is divided ("F FAC d") by the weight, i.e. $\text{reading} = \text{factor} / \text{weight}$. The range over which this factor can be selected depends on the weighing range and the readability of the model concerned.

The "free factor" (FAC M) function can, for example, be used to calculate the price of the material weighed directly or to calculate the weight per defined unit of surface area. It can also be used to convert the weight into any desired alternative unit. This facility for dividing the factor by the weight (FAC d) is required for instance in the textile industry to determine yarn count.

The ability to select the display increments makes it possible to specify how the weighing result is to be presented, the choice of display increments being limited by the set factor and the resolution of the balance model itself.

Requirement

The function "F FAC M" or "F FAC d" must be activated in the menu (Section 4).



17.89 g

F FAC M

1.0000

0.9999

⋮

0.9500

StEP=



0.01

0.02

⋮

0.05

17.00

Entering the free factor and/or the display increments

- Hold the «F» key down until "F FAC M" or "F FAC d" appears in the display.
- Press the «↶» key to select "FAC M" / "FAC d" or "noFAC M" / "noFAC d" (Function deactivated).
- Release the key. Either the factor 1 appears as default value or the factor that was saved most recently.

This value can now be changed:

- Pressing the «↶» key increases the factor.
- Pressing the «1/10d» key reduces the factor.

Pressing the key once changes the value by one increment. If the key is held down, the value changes increasingly rapidly.

- Confirm the selected factor with the «↷» key (it will not be saved automatically). "StEP=" appears in the display, and the program changes auto-matically to allow the display increments to be entered. The smallest possible display increment appears as default value, or the last value that was saved.
- This value can be changed in the same way as for the free factor (see above).
- Confirm the selected display increment with the «↷» key (it will not be saved automatically).

The appropriate calculation is then made using the weight on the pan in grams and the selected factor, the result being displayed with the selected display increment. **No units are displayed**, the symbol "#" being displayed instead. The calculation is always based on the weight in grams.

Note

- If you only want to change the display increments, set the free factor at exactly 1.

Toggling between displaying the calculated value and the measured weight

- Place the sample on the weighing pan. The appropriate calculation is then made using the weight of the sample and the selected factor, the result being displayed with the selected display increment.
- Press the «↶» key. The weight is displayed (in unit 1, and if the key is pressed again in unit 2, provided that this option is activated).
- Press the «↶» key again to return to the calculated value.

6 Technical data, options, optional equipment

6.1 Technical data

Standard equipment of JL balances

- Protective cover, transparent, made from Borex
- AC adapter to national codes
100–240 VAC/50–60 Hz, 0.3 A / 12 VDC, 0.84 A
Balance power input: 6–14.5 VAC, 50/60Hz, 4 VA or 7–20 VDC, 4 W
- All models can weigh below balance.
- Display with backlit

Materials

- Top housing: ABS plastic, PC blended
- Bottom housing:
 - JLxx3-C: die-cast aluminum, painted
 - all other JL-C/JL-G: ABS plastic, PC blended
- Auxiliary Display: PMMA (Acrylic glass)
- Weighing pan: Chromium-nickel steel, 18/10
- In-use cover: PET
- Carat pan (12102593): AlMg3

Batteries

Note: Only for all JL-G, JL503-C5 and JL502-C models

- Disposable: 4 x AA (LR6) 1.5 V alkali-manganese, typical 20 h (with 2.9 Ah capacity, without backlit)

Protection

- Protected against dust and water
- Pollution degree: 2
- Overvoltage category: class II
- EMC: see declaration of conformity

Ambient conditions

The technical data are valid under the following ambient conditions:

- Ambient temperature 10 °C ... 30 °C
- Relative humidity 10 % ... 80 % at 31 °C, linear decreasing to 50% at 40 °C, noncondensing

Operability is assured at ambient temperatures between 5 and 40 °C.

Technical data carat balances	JL603-C	JL1103-C	JL1503-C	JL503-C5¹⁾	JL502-C²⁾
Readability	0.001 ct / 0.001 g	0.001 ct / 0.001 g	0.001 ct / 0.0001 g	0.005 ct / 0.001 g	0.01 ct / 0.001 g
Max. load	610 ct / 122 g	1100 ct / 220 g	1510 ct / 302 g	510 ct / 102 g	510 ct / 102 g
Taring Range	0 ... 610 ct 0 ... 122 g	0 ... 1100 ct 0 ... 220 g	0 ... 1510 ct 0 ... 302 g	0 ... 510 ct 0 ... 102 g	0 ... 510 ct 0 ... 102 g
Repeatability (sd)	0.001 ct / 0.001 g	0.001 ct / 0.001 g	0.001 ct / 0.0004 g	0.005 ct / 0.001 g	0.01 ct / 0.01 g
Linearity	0.001 ct / 0.001 g	0.001 ct / 0.001 g	0.002 ct / 0.0008 g	0.01 ct / 0.002 g	0.02 ct / 0.01 g
Sensitivity temperature drift (10 °C ... 30 °C)	10 ppm/ °C	10 ppm/ °C	10 ppm/ °C	50 ppm/ °C	20 ppm/°C
Typical stabilization time	3 s	3 s	4 s	2.5 s	2 s
Adjustment weight external	100 g ³⁾	200 g ³⁾	200 g ³⁾	100 g ³⁾	100 g ³⁾
Level indicator	yes	yes	yes	yes	yes
Number of leveling screws	2	2	2	2	2
Weighing pan	ø 80 mm	ø 80 mm	ø 80 mm	ø 100 mm	ø 100 mm
Usable heigh of draft shield	160 mm	160 mm	160 mm	160 mm	160 mm
External dimensions of balance (W/D/H)	194/236/254 mm	194/236/254 mm	194/236/254 mm	194/236/250 mm	194/236/250 mm
External dimensions of balance with auxiliary display (W/D/H)	194/286/254 mm	194/286/254 mm	194/286/254 mm	194/286/250 mm	194/286/250 mm
External dimensions of packaging (W/D/H)	380/225/332 mm (0.0284 m ³)	380/225/332 mm (0.0284 m ³)	380/225/332 mm (0.0284 m ³)	380/225/332 mm (0.0284 m ³)	380/225/332 mm (0.0284 m ³)
Net weight (with packaging)	2.5 kg (4.2 kg)	2.6 kg (4.3 kg)	2.6 kg (4.3 kg)	1.8 kg (2.9 kg)	1.8 kg (2.9 kg)

¹⁾ no certified models available

²⁾ certified model


³⁾ included

Technical data gold balances	JL602-G	JL802-G	JL1502-G	JL1501-G	JL5001-G	JL7001-G
Readability	0.01 g	0.01 g	0.01 g	0.1 g	0.1 g	0.1 g
Max. load	610 g	810 g	1510 g	1510 g	5100 g	7100 g
Taring Range	0 ... 610 g	0 ... 810 g	0 ... 1510 g	0 ... 1510 g	0 ... 5100 g	0 ... 7100 g
Repeatability (sd)	0.01 g	0.01 g	0.01 g	0.1 g	0.1 g	0.1 g
Linearity	0.02 g	0.02 g	0.03 g	0.2 g	0.2 g	0.2 g
Sensitivity temperature drift (10 °C ... 30 °C)	10 ppm/ °C	10 ppm/ °C	10 ppm/ °C	10 ppm/ °C	10 ppm/ °C	10 ppm/ °C
Typical stabilization time	2.5 s	2.5 s	3 s	1.5 s	2 s	2 s
Adjustment weight external	500 g ¹⁾	500 g ¹⁾	1000 g ¹⁾	1000 g ¹⁾	5000 g ¹⁾	5000 g ¹⁾
Level indicator	yes	yes	yes	yes	yes	yes
Number of leveling screws	4	4	4	4	4	4
Weighing pan	∅ 160 mm	∅ 160 mm	∅ 160 mm	∅ 160 mm	∅ 160 mm	∅ 160 mm
External dimensions of balance (W/D/H) in mm	194/225/67	194/225/67	194/225/67	194/225/67	194/225/67	194/225/67
External dimensions of balance with auxiliary display (W/D/H) in mm	194/286/67	194/286/67	194/286/67	1194/286/67	194/286/67	194/286/67
External dimensions of packaging (W/D/H) in mm	350/275/140 (0.0127 m ³)	350/275/140 (0.0127 m ³)	350/275/140 (0.0127 m ³)	350/275/140 (0.0127 m ³)	350/275/140 (0.0127 m ³)	350/275/140 (0.0127 m ³)
Net weight (with packaging)	1.2 kg (2.2 kg)	1.2 kg (2.2 kg)	1.3 kg (2.3 kg)	1.3 kg (2.3 kg)	1.3 kg (2.3 kg)	1.2 kg (2.2 kg)

¹⁾ optional equipment

6.2 Options

All optional equipment must be specified when ordering the balance. When the setup needs to be changed after ordering the balance, this must be carried out by a METTLER TOLEDO service facility. All certified models are equipped with RS232C and RS232C special interfaces.




RS232C interface and interface accessories

Every balance can be equipped with an optional RS232C interface for connection to a peripheral device (e.g. printer, auxiliary display or PC with a 9-pin male connector, see Section 6.4). The balance must then be configured to suit the peripheral device in a menu dialog (Sections 4.3.9 – 4.3.12).

A detailed description of the available interface commands is given in the "Reference Manual MT-SICS B-S/L/L-S balances 11780447". This can be downloaded from the Internet (www.mt.com/sics-classic) and is only available in English.

The wide range of features of the JL balances regarding documentation of the results can be utilized by connecting to a printer, e.g. the RS-P26 or LC-P45 from METTLER TOLEDO. Printed results then make a decisive contribution to simplifying GLP/GMP-compliant work.



RS232C special interface with mini-DIN connector

(only certified models)

This interface can only be used with the **special** auxiliary display Part no. 12102508 or Part no. 72213566 (see Section 6.4). When the auxiliary display is connected, no special settings need to be made in the menu.

6.3 MT-SICS Interface commands and functions

Many of the balances and scales used have to be capable of integration in a complex computer or data acquisition system.

To enable you to integrate balances in your system in a simple manner and utilize their capabilities to the full, most balance functions are also available as appropriate commands via the data interface.

All new METTLER TOLEDO balances launched on the market support the standardized command set "METTLER TOLEDO Standard Interface Command Set" (MT-SICS). The commands available depend on the functionality of the balance.

Basic information on data interchange with the balance

The balance receives commands from the system and acknowledges the command with an appropriate response.

Command formats

Commands sent to the balance comprise one or more characters of the ASCII character set. Here, the following must be noted:

- Enter commands only in uppercase.
- The possible parameters of the command must be separated from one another and from the command name by a space (ASCII 32 dec., in this description represented as \square).
- The possible input for "text" is a sequence of characters of the 8-bit ASCII character set from 32 dec to 255 dec.
- Each command must be closed by $C_{R}L_{F}$ (ASCII 13 dec., 10 dec.).

The characters $C_{R}L_{F}$, which can be inputted using the Enter or Return key of most entry keypads, are not listed in this description, but it is essential they be included for communication with the balance.

Example**S – Send stable weight value**

Command	S	Send the current stable net weight value.
Response	S S WeightValue Unit	Current stable weight value in unit actually set under unit 1.
	S I	Command not executable (balance is currently executing another command, e.g. taring, or timeout as stability was not reached).
	S +	Balance in overload range.
	S -	Balance in underload range.

Example

Command	S	Send a stable weight value.
Response	S S 100.00 g	The current, stable weight value is 100.00 g.

The MT-SICS commands listed below is a selected list of available commands. For additional commands and further information please refer to the Reference Manual "MT-SICS 11780447" downloadable from the Internet under www.mt.com/sics-classic.

S – Send stable weight value

Command	S	Send the current stable net weight value.
---------	----------	---

SI – Send value immediately

Command	SI	Send the current net weight value, irrespective of balance stability.
---------	-----------	---

SIR – Send weight value immediately and repeat

Command	SIR	Send the net weight values repeatedly, irrespective of balance stability.
---------	------------	---

Z – Zero

Command	Z	Zero the balance.
---------	----------	-------------------

@ – Reset

Command	@	Resets the balance to the condition found after switching on, but without a zero setting being performed.
---------	----------	---

SR – Send weight value on weight change (Send and Repeat)

Command	SR	Send the current stable weight value and then send continuously the stable weight value after every weight change. The weight change must be at least 12.5 % of the last stable weight value, minimum = 30d.
---------	-----------	---

ST – Send stable weight after pressing  (transfer) key

Command	ST	Inquiry of actual status of the ST function.
---------	-----------	--

SU – Send stable weight value with currently displayed unit

Command	SU	As the "S" command, but with the currently displayed unit.
---------	-----------	--

6.4 Optional equipment

AC adapter

AC adapter universal (EU, USA, AU, UK) 100–240 VAC/50–60 Hz, 0.3 A 12 VDC, 0.84 A	11120270
--	----------

AccuPac B-S

Rechargeable external power source for 15 hours weighing operation independent of AC power supply (no Backlit)	21254691
--	----------

Adjustment weights

Available as OIML weights (E1, E2, F1, with calibration certificate); for further details see METTLER TOLEDO Weights brochure or see www.mt.com/weights	11795461
--	----------

Antitheft device

Cable with lock (for all models)	00590101
----------------------------------	----------

Auxiliary display

• Auxiliary display RS-AD-L7 ¹⁾ with backlit	72213564
• Auxiliary display RS-AD-7 ¹⁾ without backlit	72213565
• Auxiliary display PS/2-AD-L7D (for certified models only) with mini-DIN connector, backlit	72213566
• Auxiliary display (for certified models only) with mini-DIN connector, for balance mounting (incl. RS cable 1 m, adjustable base and mounting plate with screws)	12102508

Carat pan

• small, ø 80 mm x 20 mm, aluminium	12102645
• medium, ø 90 mm x 30 mm, aluminium	12102646
• large, ø 90 mm x 45 mm, aluminium	12102647

Draft shields

• Draft shield for JL-C (except for JL503-C5 and JL502-C)	12102640
• Draft shield for JL503-C5 and JL502-C	12102641

Interface

- RS232C
- RS232C special with mini-DIN connector (for optional
auxiliary display, certified models only)

The interface must be fitted in the factory. Retrofitting
is only possible if carried out by a METTLER TOLEDO
service facility.

Interface cable ¹⁾

• RS9–RS25: (m/f), length 2 m	11101052
• RS9–RS9: (m/f), length 1 m	11101051
• RS9–RS9: (m/m), length 1 m	21250066
• RS232-USB Converter cable	11103691

In-use cover

• In-use cover for JL-G, JL503-C5 and JL502-C models	12102980
• In-use cover for JL-C models (except for JL503-C5 and JL502-C)	12102587
• In-use cover for additional auxiliary display	12102592

Printer

• Application printer (LC-P45) Plain-paper printer, 24 characters, with additional functions (time, date, statistic, multiplier etc.)	00229119
• Report printer (RS-P26) Plain-paper printer, 24 characters with additional functions (time, date)	12120788

Software ¹⁾

LabX direct balance (Simple data transfer)	11120340
---	----------

Transport case

For all JL-G models (without draft shield); accommodates balance, AC adapter, batteries and weights	12102982
---	----------

Weighing pan

ø 120 mm weighing pan (+ pan holder + draft shield element for operation without a draft shield). For models with ø 160 mm weighing pan: Necessary for use together with draft shield.	12102987
---	----------



¹⁾ RS232C interface necessary

6.5 Dimensional drawings



All dimensions in millimeters (mm)

Gold balances without draft shield

JL602-G
JL802-G
JL1502-G
JL1501-G
JL5001-G
JL7001-G




Gold balances without draft shield, with auxiliary display (optional equipment, 12102508)





All dimensions in millimeters (mm)

Carat balances with draft shield




JL603-C
JL1103-C
JL1503-C



JL503-C5
JL502-C



Carat balances with draft shield and auxiliary display (optional equipment, 12102508)



7 Appendix

7.1 Typical printouts from METTLER TOLEDO RS-P26 and LC-P45 printers

Function: **Adjusting**

```

- BALANCE CALIBRATION -
04.07.2006      09:52:12

METTLER TOLEDO
Type:          JL1502-G
SNR:          1120053108
SW:           1.0

Weight ID: .....
Weight:        1000.00 g

External Cal. done

Signature:

.....
----- END -----

```

Function: **Piece counting**

Printout with reference weight

```

---- PIECE COUNTING ----
APW:          0.99 g
Out of:       10 PCS

                27.00 g
                27 PCS

```

Function: **Percent weighing**

```

----- % - WEIGHING -----
Ref.          10.008 g
              100.00 %

              60.01 g
              599.59 %

```

Function: **Free factor**

```

- FREE FACTOR WEIGHING -
Formula:      factor *
weight
Factor:       12.73
Step:         0.01

              49.94 #

```

Function: **Statistics**

Function is triggered via the printer. ¹⁾

```

04.07.2006      10:44:07
ID              666
SNR:           1118015657
1              1100.15 g
2              1600.10 g
3              1699.95 g
n              3
x              1466.733 g
s              321.372 g
srel           21.91 %
min.           1100.15 g
max.           1699.95 g
dif.           599.80 g
----- END -----

```

Function: **List**

Printout of the current balance settings

```

--- LIST OF SETTINGS ---
04.07.2006      09:52:12

METTLER TOLEDO
Type:          JL602-G
SNR:          1120053108
SW:           1.0
TDNR:         7.17.1.286.108

-----
Application:
Count
-----
Weighing Parameters:
Weighing Mode Standard
Unit              1g
Unit              2mg
A.Zero            On
-----
System Parameters:
Auto off          10 min
-----
Peripheral Devices:
P.Device          Printer
Baud              2400
Bit/Parity        7b-even
Handshake         Off

P.Device          Host
Sendmode          Off
Baud              9600
Bit/Parity        8b-no
Handshake         Soft
----- END -----

```

Function: **Verification of the calibration (adjustment) with external weight.**

Function is triggered via the printer. ¹⁾

```

----- BALANCE TEST -----
04.07.2006      09:52:12

METTLER TOLEDO
Type:          JL1502-G
SNR:          1120053108
SW:           1.0

Weight ID: .....

Target :.....
Actual :.....199.98 g
Diff   :.....

External test done

Signature:

.....
----- END -----

```

Function: **Multiplier**

Function is triggered via the printer. ¹⁾

```

04.07.2006      08:23:22
ID              242
SNR:           1118015657

Factor          1.65
                588.43 g
*              970.9095

```










Notes

The operating instructions for the LC-P45 include a description of the functions that are triggered via that printer.


The **RS-P26** prints all reports in **English**. This applies also to the LC-P45 reports that originate in the balance. In the case of reports triggered by the **LC-P45**, the following languages may be selected: **German, English, French, Spanish or Italian**.

¹⁾ Only possible with LC-P45

7.2 What if...?

Error/error message	Cause	Rectification
	Overload	→ Remove sample from weighing pan, zero again (tare).
	Underload	→ Check whether weighing pan is positioned properly.
	No stability <ul style="list-style-type: none"> • in taring or adjusting (calibration) • when reference weight for piece counting weighing is placed on the pan 	<ul style="list-style-type: none"> → Wait for stability before pressing key. → Ensure more stable ambient conditions. → Remove weighing pan and clean if necessary
	Wrong adjustment weight on pan or none at all	→ Place required adjustment weight in center of pan.
	Reference weight (Piece counting, Percent weighing, Plus-minus weighing) too small	→ Increase reference weight.
	Internal fault	→ Contact METTLER TOLEDO customer service.
	Wrong weighing pan or pan missing or not empty	→ Mount correct weighing pan.
	Adjustment aborted with the «C» key	
	No display <ul style="list-style-type: none"> • AC adapter not plugged in • Batteries discharged (not for JLxx3-C models) 	<ul style="list-style-type: none"> → Check AC power supply. → Plug AC adapter into power supply. → Replace batteries; if using rechargeables connect balance to AC power supply.

7.3 Maintenance and cleaning



Service

Regular servicing of your balance by a service technician prolongs its working life. Ask your METTLER TOLEDO dealer for details of servicing options.

Cleaning

Wipe housing and weighing pan with a soft, lint-free cloth, and – if necessary – with a mild cleaning agent, e.g. soap solution. Protect balance and weighing pan from soiling. Soiled In-use covers can be replaced on all balance types (see Section 6.3).

Note

After working with chemicals, it is advisable to wash or clean the weighing pan and the bottom plate (if draft shield fitted). Although all materials are of high quality, corrosion may occur if corrosive substances are deposited on chrome steel for an extended period of time (and if air is excluded, for example by a coating of grease).



Disposal

In conformance with the European Directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE) this device may not be disposed of in domestic waste. This also applies to countries outside the EU, per their specific requirements. Please dispose of this product in accordance with local regulations at the collecting point specified for electrical and electronic equipment.

If you have any questions, please contact the responsible authority or the distributor from which you purchased this device.

Should this device be passed on to other parties (for private or professional use), the content of this regulation must also be related.

Thank you for your contribution to environmental protection.

7.4 Declaration of conformity

The undersigned declare on behalf of

Mettler-Toledo AG
Im Langacher
CH-8606 Greifensee

that the balances **METTLER TOLEDO JL...-C / JL...-G** to which this declaration relates (serial number specified on the product) are in compliance with the below mentioned EEC Directives (including all amendments)

2006/95/EC Low Voltage Directive

2004/108/EC Electromagnetic compatibility

and that following standards have been applied: **IEC/EN61010-1:2001**,
IEC/EN61326-1:1997+ A1:98 (class B),
for Canada, USA and Australia **CAN/CSA-C22.2 No.1010.1-92**,
UL Std. No.3101-1, FCC, Part 15, class A.


Balances in certified version additionally comply with **90/384/EEC**

Non-automatic weighing instruments and standard **EN 45501**.

EC type approval No: D03-09-005

Greifensee, 03.10.2007

Mettler-Toledo AG
Laboratory & Weighing Technologies



René Lenggenhager
General Manager



Marcel Strotz
Manager SBU LAB Basic Weighing

**To protect your METTLER TOLEDO product's future:
METTLER TOLEDO Service assures the quality, measuring accuracy and preservation of value of all
METTLER TOLEDO products for years to come.
Please send for full details about our attractive terms of service.
Thank you.**



* 1 1 7 8 1 0 1 0 *

Subject to technical changes and to the availability
of the accessories supplied with the instruments.

© Mettler-Toledo AG 2007 11781010A Printed in Switzerland 0711/2.12

Mettler-Toledo AG, Laboratory & Weighing Technologies, CH-8606 Greifensee, Switzerland
Phone +41-44-944 22 11, Fax +41-44-944 30 60, Internet <http://www.mt.com>