

IND360 POWERCELL® EtherCAT PLC



Ether**CAT**®



METTLER TOLEDO

Menu

1.	Overview	1-2
2.	Setup of Project Development Environment	2-2
2.1.	Hardware Integration	2-2
2.2.	Open the Sample Code	2-3
2.3.	Set up the IND360 Input/ Output Box	2-4
2.4.	Set up the TwinCAT CoE library	2-7
2.5.	Download the Sample Programming	2-9
3.	SAI Data Structure	3-10
4.	Function Blocks	4-11
4.1.	Cyclic Weight Data Processing	4-11
4.2.	Device Heart Beat Monitoring	4-14
4.3.	Diagnostic Status Monitoring	4-15
4.4.	Read Scale Adjustment Settings	4-17
4.5.	Write Scale Adjustment Settings	4-17
4.6.	Zero Adjustment	4-18
4.7.	Span Adjustment	4-19
4.8.	CalFree+	4-22
4.9.	Read Individual Load Cell Weight Value (gross or net)	4-23
5.	Sample Code Migration	5-24
5.1.	PLC Library	5-24
5.2.	Add/ Import the Global Variable List	5-24
5.3.	Duplicate Programming Files	5-26

1. Overview

This Engineering Note is based on the integration of Mettler Toledo's Industrial Weighing Automation Terminal IND360 POWERCELL® with an EtherCAT PLC or IPC. Go to www.mt.com/ind-IND360-downloads to download all the necessary files and documents.



Note: The configuration used in this sample code is based on the default settings :

Beckhoff TwinCAT 3 PLC

SAI data format: 2-Block format

IP Address: (to be assigned by the PLC/ IPC)

IND360 device firmware version: V1.00.0015

ESI file: Mettler Toledo IND360 ESI.xml

It is recommended to start by integrating one IND360 into the PLC EtherCAT network and go through the sample code to understand the functionality of each Function Block.

2. Setup of Project Development Environment

2.1. Hardware Integration

Connect the Ethernet cable from the PLC EtherCAT port to IND360 industrial Ethernet port (X1.1 or X1.2).

2.2. Open the Sample Code

To open and use this sample project "IND360_POWERCELL_ETCAT_V1_00" or solution, you need to use the BECKHOFF TwinCAT 3 – eXtended Automation Engineering (XAE) version 3.1 or higher.

Copy and paste the IND360 ESI (EtherCAT Slave Information) specification onto the TwinCAT\3.1\Config\io\ EtherCAT directory.




Figure 2-1: copy and paste the IND360 ESI specification

Reload the TwinCAT devices as shown below:




Figure 2-2: reload the EtherCAT devices' descriptions

2.3. Set up the IND360 Input/ Output Box

In this sample code, the IND360's SAI data format is the default "2 block format". This can also be configured as "8 block format" via the web browser. IND360's web configuration can be accessed by connecting the Ethernet cable to its service port with default IP address "192.168.0.8". SAI data structure will be explained in brief in Chapter 3 – SAI Data Structure. For detailed information regarding METTLER TOLEDO's SAI protocol please go to this [document](#) on MT.com.




Figure 2-3: SAI data format can be 2 block or 8 block

In the TwinCAT input/ output box configuration, check the 2-Block data only. Do the same for both Inputs and Outputs.




Figure 2-4: configure Inputs as 2-Block




Figure 2-5: configure Outputs as 2-Block

Online reload the connected EtherCAT device and check the cyclic communication of all input/output data.




Figure 2-6: online reload the EtherCAT device

2.4. Set up the TwinCAT CoE library

Besides supporting the cyclic communication used in process control, the IND360 EtherCAT device also supports the SDO (Service Data Object) configuration via CoE interface (CAN application protocol over EtherCAT). These SDOs are mainly for scale configuration (capacity, increment, filter settings etc.) and scale calibration (adjustment).

In order to enable the SDO read/write, the TwinCAT CoE library "Tc2_EtherCAT" has to be added into the PLC project references.




Figure 2-7: make sure the Tc2_EtherCAT is added

Function blocks "FB_EcCoESdoWrite" and "FB_EcCoESdoRead" are used in this sample code to write/ read the SDO via CoE interface. In order to use these function blocks, the EtherCAT device's NetID and Slave Address are required. These two inputs will be different for every connected EtherCAT slave.

```
fbStatus CoESdoRead(  
  sNetId      := deviceNetId,  
  nSlaveAddr  := deviceSlaveAddr,  
  nSubIndex   := 0,  
  nIndex      := 16#4007,  
  pDstBuf     := ADR(intStatus),  
  cbBufLen    := SIZEOF(intStatus),  
  bExecute    := bRead,  
  tTimeout    := T#2S  
);
```

Figure 2-8: the EtherCAT slave's NetID and Slave Address for CoE write/read function block

The EtherCAT device's NetID and Slave Address can be found as shown below.




Figure 2-9: EtherCAT Device NetID




Figure 2-10: EtherCAT Device Slave Address as "1001"

2.5. Download the Sample Programming

Build the solution, then activate the configuration:






Figure 2-11: Activate the current configuration

Login to the PLC , and run the application .

3. SAI Data Structure

In this sample code, the IND360's SAI data format is the default "2 block format". This can also be configured as "8 block format" via the web browser. For more details on SAI data structure, please refer to the User Manual: Standard Automation Interface: IND360 Terminal English, which is downloadable from the IND360 Download Page www.mt.com/ind-IND360-downloads.

SAI 2 Block Format consists of a single Floating Point Block and a Status Block. In the figure below, the Read and Write are referring to the PLC point of view.

Floating Point Block (Read)	
Word 0	Requested floating point value (32-bit)
Word 1	
Word 2	Device status bits
Word 3	Response value

Floating Point Block (Write)	
Word 0	Floating point value (32-bit), optionally used with command
Word 1	
Word 2	Channel mask
Word 3	Command value

Status Block (Read)	
Word 0	Status Group 1
Word 1	Status Group 2
Word 2	Status Group 3
Word 3	Response value

Status Block (Write)	
Word 0	Optional Argument – word0
Word 1	Optional Argument – word1
Word 2	Optional Argument – word3
Word 3	Command value

Figure 3-1: SAI 2 Block Data Structure

The SAI 8 Block Format builds on the format structure used by the 2 Block format; providing support for eight blocks of input data and eight blocks of output data. This format was designed for applications where the users would prefer more data within one read cycle. For example, reading gross weight, tare weight and net weight all in one cycle.

The cyclic data of the 8 Block Format supports seven instances of a Floating Point Block and one instance of a Status/Command Block for each of the read and write data areas.

Floating Point Block (Read)	Floating Point Block (Write)
Status Block (Read)	Status Block (Write)
Floating Point Block (Read)	Floating Point Block (Write)
Floating Point Block (Read)	Floating Point Block (Write)
Floating Point Block (Read)	Floating Point Block (Write)
Floating Point Block (Read)	Floating Point Block (Write)
Floating Point Block (Read)	Floating Point Block (Write)
Floating Point Block (Read)	Floating Point Block (Write)

Figure 3-2: SAI 8 Block Data Structure

4. Function Blocks

Ready-to-use function blocks (FB) can be found under the POU's folder. These function blocks are being called in the program "MT_IND_Application".




Figure 4-1: read-to-use Function Blocks (FB) under the POU's folder

4.1. Cyclic Weight Data Processing

This function block reads in all the important real-time, cyclical weighing data such as weight value, Data OK bit, Motion bit, Net mode bit and critical alarm bit.

Set the scale command bit one at a time to trigger different commands such as tare stable, zero stable, tare immediate, zero immediate, preset tare and clear tare. A successful execution of a scale command will set the Done bit on, else the Error bit will be set on instead.

The cyclic weight data can be reported automatically right after any scale command. The type of weight data (gross, net, or tare) being reported depends on the setting for WeightCmd. By default, the WeightCmd is decimal "3" and the function block will return a net weight value every time

after any scale command such as tare or zero. Similarly, if the WeightCmd parameter is configured as decimal "0" or "1" the function block will then return a gross weight after any scale command.




Figure 4-2: SAI_Cyclic_WeightProc Function Block

Table 4-1: SAI_Cyclic_WeightProc Function Block Parameters

Input Parameters	Data Type	Values	Description
WeightCmd	Word	0, 1	Report gross weight value
		2	Report tare weight value
		3 (default)	Report net weight value
		5	Report gross weight value (with internal resolution)
		6	Report tare weight value (with internal resolution)
		7	Report net weight value (with internal resolution)
MB_DeviceStatus	Word		Refer to Device Overview, input address of MB Device Status
TareImmediate_cmd	Bool		Trigger this bit to perform immediate tare command. This tare command doesn't check for stability criteria. Upon completion of this command, the input bit will be reset.
TareStable_cmd	Bool		Trigger this bit to perform stable tare command. This tare command requires the weight value to remain stable within the stability criteria (+1d within 0.3 second) for a predefined timeout range (3 seconds by default), failing which, the command will return an error. Upon completion of this command, the input bit will be reset.
ZeroImmediate_cmd	Bool		Trigger this bit to perform immediate zero command. The zero command can only be executed when the weight value is within the zero range (+2% by default). Else, the command will return an error. Upon completion of this command, the input bit will be reset.

ZeroStable_cmd	Bool		Trigger this bit to perform a stable zero command. This zero command requires the weight value to remain stable within the stability criteria (+-1d within 0.3 second) for a predefined timeout range (3 seconds by default). Furthermore the weight value has to be in the zero range to trigger this command, failing either condition; the command will return an error. Upon completion of this command, the input bit will be reset.
PreTareValue	Real		The preset tare value which has to be configured before issuing the PreTare command. Valid PreTare value is between scale's zero point up to maximum capacity.
PreTare_cmd	Bool		Trigger this bit to perform a preset tare command. The PreTareValue has to be configured prior to issuing this PreTare command. Upon completion of this command, the input bit will be reset.
ClearTare_cmd	Bool		Trigger this bit to perform a clear tare command. This command removes the tare and brings the scale into gross mode. Upon completion of this command, the input bit will be reset.
MB_MeasuredValue	Real		Refer to EtherCAT device's Box, MB1 Requested Measuring Value
MB_Response	Word		Refer to EtherCAT device's Box, MB1 Response
MB_CmdValue	Real		Refer to EtherCAT device's Box, MB1 Command Value
MB_Command	Word		Refer to EtherCAT device's Box, MB1 Command
Output Parameters	Data Type	Values	Description
realtimeWeight	Real		Real-time weight value, can be gross, tare or net weight
stableWeight	Real		Stable weight value, the last real-time weight during Motion = 0
heartBeat	Bool	0>1>0>1...	Is a security mechanism that ensures that the device is working as expected and updating data in Words 0, 1 and 2, this heartbeat bit is toggled between off and on states at a rate of 1 time per second or less. Should this bit stop toggling, this indicates that the device is no longer operating and the weight value is incorrect.
DataOK	Bool	0	<p>This bit gets set to 0 when the device is still operational but the value being reported cannot be guaranteed to be valid.</p> <p>The following conditions cause the Data Okay bit to be set to 0:</p> <ul style="list-style-type: none"> • Device is powering up • Device is in setup mode • Device is in test mode • Over capacity condition occurs <ul style="list-style-type: none"> - When the A/D converter is at its limit - Product dependent over capacity that occurs when the device determines it cannot trust the weight • Under capacity condition occurs <ul style="list-style-type: none"> - When the A/D converter is at its limit

			- Product dependent under capacity that occurs when the device determines it cannot trust the weight
		1	Weight data is normal, valid
Smart5_red	Bool	0/1	Also referred as Smart 5 level 5, RedAlert condition in which scale operation has to be stopped
Smart5_orange	Bool	0/1	Also referred as Smart 5 level 4, imminent failure of the scale
Smart5_yellow	Bool	0/1	Also referred as Smart 5 level 3, out of specification or wrong operator step
Smart5_blue	Bool	0/1	Also referred as Smart 5 level 2, predictive alarm or calibration/ adjustment is due
centerofZero	Bool	0/1	1 = Gross weight value is at a value of zero +/- one quarter of a weight and measures verification interval denoted as "e".
motion	Bool	0	Weight value is stable
		1	Weight value is in motion
netMode	Bool	0	Weighing is in gross mode
		1	Weighing is in net mode
runFlat	Bool	0	RunFlat is inactive
		1	RunFlat is active
cmdDone	Bool	0	Zero, tare or clear tare command is in process, or failed
		1	Zero, tare or clear tare command is successful
cmdPending	Bool	0	Zero or tare command is completed
		1	Zero or tare operation is being processed, pending due to unstable (motion) environment.
cmdFailed	Bool	0	Zero, tare or clear tare command is in process, or succeeded
		1	Zero, tare or clear tare command is not completed due to error

4.2. Device Heart Beat Monitoring

This function block monitors the Heart Beat bit of the weighing transmitter and outputs an "Alive" flag.




Figure 4-3: SAI_Cyclic_CheckAlive Function Block

Table 4-2: SAI_CyclicCheckAlive Function Block Parameters

Input Parameters	Data Type	Values	Description
MB_DeviceStatus	Word		Refer to EtherCAT device's Box, MB1 Scale Status
Output Parameters	Data Type	Values	Description
Alive	Bool	0	Device has lost communication

		1	Device is communicating OK
HeartBeat	Bool		To insure that the device is working as expected and updating data in Words 0, 1 and 2, this heart beat bit is toggled between off and on states. The frequency is dependent on the specific device's ability to cycle this bit. For example, a 1 second heart beat would be sufficient for most applications.

4.3. Diagnostic Status Monitoring

This function block reads in all the critical real-time diagnostic data from POWERCELL® load cells.




Figure 4-4: SAI_INDPCELL_DiagnosticStatus Function Block

Table 4-3: SAI_INDPCELL_DiagnosticStatus Function Block Parameters

Input Parameters	Data Type	Values	Description
SB_StaGroup1	Word		Refer to Device Overview, input address of SB Status Group 1
SB_StaGroup2	Word		Refer to Device Overview, input address of SB Status Group 2
SB_StaGroup3	Word		Refer to Device Overview, input address of SB Status Group 3
SB_Response	Word		Refer to Device Overview, input address of SB Response
SB_Command	Word		Refer to Device Overview, output address of SB Command
Output Parameters	Data Type	Values	Description

CalibrationError	Bool	0, 1	1 = Weight data can no longer be trusted due to loss of calibration data or an algorithm running in the product to detect weighing irregularities.
WeightBlocked	Bool	0, 1	1 = Weight data does not change appreciably over a defined period of time.
Overload	Bool	0, 1	The weight is equal to or greater than a "customer-programmed" limit either on the scale (multi-sensor system) or individual sensor's capacity
Underload	Bool	0, 1	The weight is under the "customer-programmed" limit on the scale / sensor (under zero but still within A/D range)
CellMissing	Bool	0	All load cells are communicating normally
		1	One or multiple load cell has lost communication
CellMissingNode	Word		A word of 16 bits, each bit represents the communication status of the POWERCELL® load cell. Bit status "1" means the load cell has lost communication, while status "0" means no comm. lost. The IND360 POWERCELL® supports up to 14 digital load cells hence only 14 bits (bit 0 – bit 13) are relevant in this Word. Word: 0 0 X X X X X X X X X X X X X X LC#14 LC#1
NetworkFailure	Bool	0, 1	Applicable only on multi-cell networks. 1 = Failure of the entire network. No cells are responding.
WMFailure	Bool	0, 1	1 = The product is no longer in compliance with weights and measure regulations.
OverUnderVoltage	Bool	0, 1	1 = A device which supports dynamic measurements of system power has over or under voltage.
CellBreach	Bool	0, 1	the sensors enclosure has been compromised and therefore vulnerable to outside influences such as moisture / water – in most cases a failure will occur if the breach is not corrected or the sensor replaced
RunFlat	Bool	0, 1	1 = RunFlat is activated on one of the POWERCELL® load cell
Smart5_lvl4	Bool	0, 1	Imminent failure according to Smart5 definition
Smart5_lvl3	Bool	0, 1	Out of specification according to Smart5 definition
Smart5_lvl2	Bool	0, 1	Predictive Alarm according to Smart5 definition
LFTSwitchON	Bool	0, 1	1 = weights and measures switch is enabled for transactional weighing

4.4. Read Scale Adjustment Settings

This function block reads the current scale capacity and increment values from the connected weighing transmitter. Set the "Read" input parameter on to start the reading process. Upon completion of the read process, this "Read" bit will be reset.

It is useful to know the current scale settings before performing any scale adjustment procedure.




Figure 4-4: SAI_IND_ReadAdjustSettings Function Block

Table 4-4: SAI_IND_ReadAdjustSettings parameter descriptions

Input Parameters	Data Type	Values	Description
deviceNetId	T_AmsNetId	Example: "192.168.0.106.3.1"	sNetId: String containing the AMS network ID of the EtherCAT master device. (type: T_AmsNetId)
deviceSlaveAddr	UINT	"1001"	nSlaveAddr: Fixed address of the EtherCAT slave to which the SDO upload command should be sent.
Read	Bool	1, 0	Trigger this input bit to start the reading process.
Output Parameters	Data Type	Values	Description
scaleCapacity	REAL (32 bits)	Example: "3000.0"	Current scale capacity value
scaleIncrement	REAL (32 bits)	Example: "0.1"	Current scale increment value
Done	Bool	1	Read process is completed successfully
		0	Read process is not completed
Error	Bool	1	An error has occurred during the read process
		0	No error

4.5. Write Scale Adjustment Settings

This Function Block configures the new settings of scale capacity and increment value onto the weighing transmitter. Even though all IND360 weighing transmitters now support scale configuration through its built-in web server, the PLC can also overwrite these scale settings. The scale resolution (scale capacity/increment) has to be within the range of 500 – 100 000.




Figure 4-5: SAI_IND_WriteAdjustSettings Function Block

Table 4-5: SAI_IND_WriteAdjustSettings parameter descriptions

Input Parameters	Data Type	Values	Description
deviceNetId	T_AmsNetId	Example: "192.168.0.106.3.1"	sNetId: String containing the AMS network ID of the EtherCAT master device. (type: T_AmsNetId)
deviceSlaveAddr	UINT	"1001"	nSlaveAddr: Fixed address of the EtherCAT slave to which the SDO upload command should be sent.
scaleCapacity	REAL (32 bits)	Example: "3000.0"	New scale capacity value
scaleIncrement	REAL (32 bits)	Example: "0.1"	New scale increment value
Write	Bool	1, 0	Trigger this input bit to start the writing process.
Output Parameters	Data Type	Values	Description
Done	Bool	1	Write process is completed successfully
		0	Write process is not completed
Error	Bool	1	An error has occurred during the write process
		0	No error

4.6. Zero Adjustment

Zero calibration has to be performed first before CalFree+ or span calibration. Make sure the scale is empty before starting this zero calibration procedure.

Trigger the "Start" input bit to start the zero adjustment process. Upon completion of the adjustment process, this "Start" bit will be reset.




Figure 4-6: SAI_IND_ZeroAdjust Function Block

Table 4-6: SAI_IND_ZeroAdjust Function Block Parameters

Input Parameters	Data Type	Values	Description
deviceNetId	T_AmsNetId	Example: "192.168.0.106.3.1"	sNetId: String containing the AMS network ID of the EtherCAT master device. (type: T_AmsNetId)
deviceSlaveAddr	UINT	"1001"	nSlaveAddr: Fixed address of the EtherCAT slave to which the SDO upload command should be sent.
Start	Bool	1, 0	Trigger this input bit to start the calibration process.
Output Parameters	Data Type	Values	Description
Process	Bool	1	Adjustment is started and in process
		0	Adjustment is not started
Done	Bool	1	Adjustment is completed successfully
		0	Adjustment is in process or in error state
Error	Bool	1	Adjustment failed due to error
		0	No error

4.7. Span Adjustment

Perform this linearity span adjustment after the zero adjustment.




Figure 4-7: SAI_IND_SpanAdjust Function Block

If only 2 points adjustment (zero, span) is required, only configure the highest reference weight (span) into this Function Block. In this case, the span is the second linearity point. The first reference point is always the zero reference which has to be adjusted prior to this.

If linearity adjustment is required, up to 4 points can be set-up. The table below shows all the possible selection of linearity adjustment and the required input parameters for this Function Block.

LinearityRange settings:	Required reference weight(s), cannot be zero:
"0", 2-point (zero, span)	HI_Weight
"1", 3-point linearity	HI_Weight, MID_Weight
"2", 4-point linearity	HI_Weight, MID_Weight, LOW_Weight

"3", 5-point linearity	HI_Weight, MID_Weight, LOW_Weight, xLOW_Weight
------------------------	--

Table 4-7: SAI_IND_SpanAdjust Linearity Range Settings

Notes:

- The Function Block will return an error if the reference weights are not configured according to the linearity range setting.
- The Function Block will return an error if the required reference weight(s) is zero or not in the correct ascending order when starting the adjustment process.

The flow chart below explains the linearity adjustment process flow according to different selection of linearity range:




Figure 4-8: SAI_IND_SpanAdjust Flow Chart

Configure the required Linearity Range and all the respective reference weights. Set the Start bit on to run the adjustment process. Wait for the LoadWeight output bit to turn on and then load the reference weight according to CurrentWeight value. After the new reference weight has been loaded, set the ConfirmWeight bit on to proceed with adjustment. Repeat the same sequence for the rest of the reference weights until the adjustment process is completed. The adjustment process can be cancelled at any point of time after started.

Table 4-8: SAI_IND_SpanAdjust Function Block Parameters

Input Parameters	Data Type	Values	Description
------------------	-----------	--------	-------------

deviceNetId	T_Ams NetId	Example: "192.168.0.1 06.3.1"	sNetId: String containing the AMS network ID of the EtherCAT master device. (type: T_AmsNetId)
deviceSlaveAddr	UINT	"1001"	nSlaveAddr: Fixed address of the EtherCAT slave to which the SDO upload command should be sent.
HI_Weight	REAL (32 bits)	Example: "800.00"	The highest reference weight in linearity calibration. For a 2-point calibration, this is the span value.
MID_Weight	REAL (32 bits)	Example: "600.00"	For a 5-point calibration, this is the 4 th reference point. For a 3-point calibration, this is the 2 nd reference point.
LOW_Weight	REAL (32 bits)	Example: "400.00"	For a 5-point calibration, this is the 3 rd reference point. For a 4-point calibration, this is the 2 nd reference point.
xLOW_Weight	REAL (32 bits)	Example: "200.00"	The lowest reference weight value in linearity calibration. Only used when the linearity range is configured to "3" – 5-point linearity.
linearityRange	INT	0, 1, 2, 3	Decimal "0" – 2-point; Decimal "1" – 3-point; Decimal "2" – 4-point; Decimal "3" – 5-point
Start	Bool	1, 0	Trigger this input bit to start the calibration process.
confirmWeight	Bool	1, 0	User has to trigger this input bit after loading the "CurrentWeight" onto the scale. This bit serves as an acknowledgement flag for the Function Block to proceed to next steps. The Function Block will reset this bit automatically.
Cancel	Bool	1, 0	Trigger this input bit to cancel/ abort the calibration process after being started.
Output Parameters	Data Type	Values	Description
currentPoint	INT	Example: "2"	The Function Block updates the current reference point here.
currentWeight	REAL (32 bits)	Example: "400.00"	The Function Block updates the required reference weight here.
loadWeight	Bool	1	User has to load a new reference weight according to the value displayed in CurrentWeight.
		0	No action required from the user
Process	Bool	1	Adjustment is started and in process
		0	Adjustment is not started
Done	Bool	1	Adjustment is completed successfully
		0	Adjustment is in process or in error state
Error	Bool	1	Adjustment failed due to error
		0	No error
Cancelled	Bool	1	Adjustment is cancelled successfully
		0	No cancellation

4.8. CalFree+

The IND360 POWERCELL® transmitter provides a method to calibrate a scale without using test weights. This is based on the POWERCELL load cell rated capacity and count value. This method can be used for initial check-out and testing of systems or when a large structure is used as the weighing vessel and it is not possible to apply test weights to the structure.

METTLER TOLEDO highly recommends that the test weights or RapidCal™ method be used whenever possible as these methods provide the most accurate calibration accuracy.

Set the Start bit on to run the CalFree+ adjustment. Upon completion of the adjustment process, this Start bit will be reset.




Figure 4-9: SAI_IND_CalFreePlus Function Block

Table 4-9: SAI_IND_CalFreePlus Function Block Parameters

Input Parameters	Data Type	Values	Description
deviceNetId	T_AmsNetId	Example: "192.168.0.106.3.1"	sNetId: String containing the AMS network ID of the EtherCAT master device. (type: T_AmsNetId)
deviceSlaveAddr	UINT	"1001"	nSlaveAddr: Fixed address of the EtherCAT slave to which the SDO upload command should be sent.
Start	Bool		Trigger this input bit to start the calibration process.
Output Parameters	Data Type	Values	Description
Process	Bool	1	Adjustment is started and in process
		0	Adjustment is not started
Done	Bool	1	Adjustment is completed successfully
		0	Adjustment is in process or in error state
Error	Bool	1	Adjustment failed due to error
		0	No error

4.9. Read Individual Load Cell Weight Value (gross or net)




Figure 4-10: SAI_INDPCELL_LoadCellWeight Function Block

Only in a POWERCELL® scale, the control system is able to read individual load cell weight value. The availability of these individual load cell weight values can be used to monitor the tank/platform load distribution. Uneven load distribution might be caused by permanent feeder and machinery attached to the scale or when weighing powder or granules. Nonetheless, the load distribution for each load cell should not differ too much from the others. When huge disparity of load distribution is detected, there could be mechanical structure failure on the scale.

Table 4-9: SAI_INDPCELL_LoadCellWeight Function Block Parameters

Input Parameters	Data Type	Description
deviceNetId	T_AmsNetId	sNetId: String containing the AMS network ID of the EtherCAT master device. (type: T_AmsNetId)
deviceSlaveAddr	UINT	nSlaveAddr: Fixed address of the EtherCAT slave to which the SDO upload command should be sent.
Read	Bool	Trigger this input bit to start the read process.
Net	Bool	Net = 0; Read individual load cell gross weight Net = 1; Read individual load cell net weight
Output Parameters	Data Type	Description
totalWeight	REAL (32 bits)	The total gross or net weight of all the load cells combined
cellWeight1	REAL (32 bits)	The load cell #1's gross or net weight
cellWeight2	REAL (32 bits)	The load cell #2's gross or net weight
cellWeight3	REAL (32 bits)	The load cell #3's gross or net weight
cellWeight4	REAL (32 bits)	The load cell #4's gross or net weight
cellWeight5	REAL (32 bits)	The load cell #5's gross or net weight
cellWeight6	REAL (32 bits)	The load cell #6's gross or net weight
cellWeight7	REAL (32 bits)	The load cell #7's gross or net weight
cellWeight8	REAL (32 bits)	The load cell #8's gross or net weight
Done	Bool	1; The read process is completed successfully 0; The read process is in processor there is an error

Error	Bool	1; There is an error during the read process
		0; No error

5. Sample Code Migration

5.1. PLC Library

As already explained in section 2.4 – Set Up the TwinCAT CoE Library, the Tc2_EtherCAT is required in order to access the SDO variables through the CoE communication.

The working PLC library is shown below.




Figure 5-1: the working PLC library

5.2. Add/ Import the Global Variable List

Certain EtherCAT device input and output variables were declared in the GVL – Global Variable List. These GVLs can be copied over or imported into another TwinCAT project/ solution.




Figure 5-2: the GVLs in the sample code

These GVLs are linked to the EtherCAT device's Box as shown below.




Figure 5-3: the input/output variables being linked to the GVLs

If a new PLC variable needs to be linked to the EtherCAT device's input/ output, this can be done by right-clicking on the "Linked to" field, Change Link... and choose the correct the PLC variables.




Figure 5-4: creating new link under the Box, TxPDO or RxPDO

5.3. Duplicate Programming Files

- 1) The required POU's:
 - a) MT_IND_Application (PRG)
 - b) SAI_Cyclic_WeightProc (FB),
 - c) SAI_Cyclic_CheckAlive (FB),
- 2) The function blocks below are optional. They are used to perform scale adjustment from the PLC. All variants of IND360 now support scale adjustment via built-in web browser.
 - d) SAI_IND_CalFreePlus (FB)
 - a) SAI_IND_ZeroAdjust (FB)
 - b) SAI_IND_SpanAdjust (FB)
 - c) SAI_IND_WriteAdjustSettings (FB),
 - d) SAI_IND_ReadAdjustSettings (FB)

The other function blocks can be added into the programming if required.

- 3) MT_IND_Application is the program which runs all the Function Block instances.




Figure 5-5: MT_IND_Application calls all the Function Blocks

- 4) POU's can be easily exported and imported into another solution.




Figure 5-6: importing and exporting POU's from this sample code