

IND360 POWERCELL

To upgrade IND360 POWERCELL firmware to version 2.05.0008, choose one of the two methods below based on current firmware version.

Current firmware version can be found in the web interface under Device --> Info recall --> Main SW.

If the current version is 2.02.0000 or higher , use method 1	
	Method 1: upgrade the firmware using the file IND360_WebUpgrade_POWERCELL_Method1_2.05.0008.mtb
If the current version is lower than 2.02.0000 , use method 2 (2 steps)	
	Method 2: Step 1: Upgrade the firmware using the file IND360_WebUpgrade_POWERCELL_Method2_Step1_2.05.0008.mtb Step 2: Upgrade the firmware using the file IND360_WebUpgrade_POWERCELL_Method2_Step2_Stack_1.02.0003.mtb