


# Báscula Portátil de Mesa *WILDCAT*® Instrucciones de Operación

## Consignes D'utilisation de la Bascule *WILDCAT*®




<b>ENCENDIDO/APAGADO</b>	<b>ON/OFF</b>
<p>Pulse y mantenga por 3 segundos — Appuyez sur on/off et maintenez pendant trois secondes —</p>	
<b>CERO</b>	<b>ZÉRO</b>
<b>NETO</b>	<b>NET</b>
<b>BRUTO</b>	<b>BRUT</b>
<b>PANTALLA ILUMINADA</b>	<b>AFFICHAGE RÉTROÉCLAIRÉ</b>
<p>Si usted tiene una pantalla iluminada — Si vous avez un affichage rétroéclairé —</p>	
<b>IMPRIMIR</b>	<b>IMPRESSION</b>

**METTLER TOLEDO**



B15610100A

# WILDCAT® Scale OPERATING INSTRUCTIONS




## ON/OFF


Press and hold for 3 seconds



## ZERO



## NET




## GROSS




## BACKLIT DISPLAY

If you have a backlit display —



## PRINT



**METTLER TOLEDO**



B15610100A