

Quality.

Technical Report No. 71308705

dated 23.06.2006

Client:

Mettler - Toledo GmbH Unter dem Malesfelsen 34 D-72458 Albstadt-Ebingen

Manufacturer and / or location of manufacturing:

see client.

Unit under test (UUT):

Terminal ID30-HMI-Box6.

Test specification:

Sealing test re. test of degree of protection provided by enclosure in

accordance to DIN 60529.

Test scope:

Verification of suitability for intended application according the

under position 3 detailed test specification.

Test result:

The unit under test was opened. The visual inspection showed no

deficiencies or damages.

The test requirements were met.

This report shall not be reproduced except in full. The use for advertising purposes requires written approval of TÜV SÜD Product Service GmbH. The test results relate only to the items tested and do not give a general evaluation about the quality of the running production.

TÜV SÜD Product Service GmbH Dudenstraße 28 D-68167 Mannheim

Editor: A.Blem

Phone: +49-621-395-277 Telefax: +49-621-395-604

Report No.: 71308705 page 1of 5

Date of issue: 23.06.2006

Accredited Test Laboratory
Deutsche Akkreditierungsstelle Technik
(DA Tech) e. V:
DAR-Reg.No. DAT-P—087/99-11



Table of content

Competence. Certainty. Quality.

- 1 Unit under test (UUT)
- 2 Test scope
- 2.1 Date of order, initial of client
- 2.2 Receipt of UUT
- 3 Test specification
- 4 Test equipment
- 5 Test sequence
- 6 Photo documentation



Competence. Certainty. Quality.

1 Unit under test (UUT)

The unit under test was a terminal.

Type: ID30-HMI-Box6 Serial-No.: PT 2006 - 06

2 **Test scope**

2.1 Date of order, initial of client

Company Mettler - Toledo GmbH orders from TÜV SÜD Product Service GmbH with order sheet dated 30.05.2006, to test the a.m. UUT.

2.2 **Receipt of UUT**

The sample was delivered on 31.06.2006 by the client.

3 **Test specification**

3.1 Degree of protection

3.1.1 IP 6X

Housing of UUT connected to a vacuum pump with a low air pressure at 2 kPa (20 mbar).

Test duration:

8 h; flow rate of air volume < 40-fold per h

3.1.2 IP X9K (Test was happened by ICT)

fan nozzle

distance nozzle to UUT: 100 mm to 150 mm water flow rate: 14 I/min to 16 I/min

water temperature:

80°C ± 5°C

water pressure:

8000 kPa to 10000 kPa

spray in position:

0°, 30°, 60°, 90° 30 s per position

test duration: UUT on rotary table:

rpm (5 ± 1)/min

Dudenstraße 28 D-68167 Mannheim

Report No.: 71308705

page 3of 5

Editor: A.Blem

Phone: +49-621-395-277

Telefax: +49-621-395-604

Date of issue: 23.06.2006



Competence. Certainty. Quality.

4 Test equipment

Equipment	Туре	SerNo.	Manufacturer
Dust chamber:	1000 ST		Weiss
Splash chamber steamjet	SWK		Brabender Falch

The measuring equipment is calibrated regularly according to the calibration instructions of TÜV SÜD PRODUCT SERVICE GmbH. All calibrations are traced back to national standards.

5 Test sequence

No.	Test	Test date	Notes
1	Protection against water - IP X9K	09.06.2006	
2	Protection against solid foreign objects - IP 6X	21.06.2006	

Edited Signature

Alexander Blem, Haridimos Mountogianakis

Test Engineer

Verified Signature

Wolfgang Jakobi Dept. Manager

Phone: +49-621-395-277



Product Service

Competence. Certainty. Quality.

6 Photo documentation

Photo 1: dust test




Photo 2: terminal, opened



Photo 3: terminal, opened




Photo 4: terminal, opened

