

Automatic Wrapping and Labeling with Maximum Film Savings



# **Increase Productivity** and Save Film and Space



Model 8361 Smart*Touch*®

Prepack Controller

- Wrap up to 30 packs per minute
- Impressive ROI with film savings alone
- 4-way film stretch for tight attractive wrap
- Automatic tray sizing...no selection required
- Apply up to 3 labels...price, merchandising, bottom label, plus security tags

The SOLO® MAX and SOLO® XL automatic wrappers are ideally suited to your mid to high volume wrapping needs with speeds up to 30 packs per minute...and no changeover time or selection between different tray sizes is required. The SOLO® MAX and XL use only a 13" film roll to wrap all trays, even family packs...25, 7, and 10 x 14. The SOLO® XL is also available in an 11" film version to match your specific application.

Both wrappers allow you to easily select film tightness...standard tight stretch for most packs and a reduced stretch wrap for sharp edge or delicate products.

An optional extended infeed conveyor is available for the SOLO MAX to provide the ability to "flood feed" the wrapper and achieve maximum throughput and productivity.

# SmartTouch® Prepack Controller

The SmartTouch Prepack Controller is a programmable prepack controller featuring an easy-to-use touchscreen. A simple touch of a finger accomplishes most tasks making operator training fast and easy to learn. For quick PLU look up, 1400 preset keys and more are available. Fast operation with reduced training time means increased profits.

### **Auto-Labelers**

The Model 706 and 705 Auto-Labeler indexes, weighs, and applies both price and optional merchandising labels and security tags to wrapped packages. Compact design and non-corrosive material construction make them ideally suited for perishables production areas. The built-in scale provides fast, accurate weight...and there is easy access to the weighing area for weighing and labeling pre-wrapped packages.

The Model 710 Bottom Label Printer applies bottom labels to your packages automatically. Any information you can print on top, you can now print on the bottom.

### **Label Printers**

The Model 317 Thermal Label Printer includes many value-added features such as fast print speed, large label capacity, graphics printing, and high resolution. You get label printing of text in multiple font sizes, graphics, safe handling, and nutrition facts. To reduce your labor costs, you can include two 317 printers with the Model 706 or 705 Auto-Labeler...one to print and apply the price label and the second to print and apply merchandising labels.



	SOLO MAX	SOLO XL-13	SOLO XL-11
	w/Auto-Labeler	w/Auto-Labeler	w/Auto-Labeler
Tray Sizes	2S, 17S, 20S, 4S, 8S, 9,10S,	2S, 17S, 20S, 4S, 8S, 9,10S,	1S, 2S, 17S, 20S, 4S, 8S,10S,
	16S, 12S, 7, 25S, 10x14	16S, 12S, 7, 25S, 10x14	16S, 7, 25S
Film Size	13″	13″	11″
Footprint (square feet)	33	25	25
DayGlo Option	Yes	Yes	Yes
<b>Bottom Printer Option</b>	Yes	Yes	Yes
Security Tag Option	Yes	Yes	Yes
Wrap/Label PPM	30 (Model 706)	23 (Model 706)	23 (Model 706)
	20 (Model 705)	20 (Model 705)	20 (Model 705)
Electrical (Wrapper)	208 or 230 VAC,	115, 208, or 230 VAC,	115, 208, or 230 VAC,
	50-60Hz, 3 kVA	50-60Hz, 3 kVA	50-60Hz, 3 kVA
Electrical (Labeler)	115 VAC, 60 Hz or 230 VAC	115 VAC, 60 Hz or 230 VAC	115 VAC, 60 Hz or 230 VAC
	50/60 Hz Single Phase, 575VA	50/60 Hz Single Phase, 575VA	50/60 Hz Single Phase, 575VA



Add the Model 710 Bottom Printer for enhanced merchandising possibilities and more attractive packages for your customers. Secure your products with the Model 703 Security Tag Applicator.





Features of the SOLO® Wrapper Family

SOLO® Wrappers are designed to use a single roll of film that results in tremendous film savings. Features include:

- Stock only one size of film.
- Remote diagnostic monitoring.
- 4-Way Film Stretch.
- Easy operation with fast film change.
- Consistent package appearance.
- Computer diagnostics.

### **Mettler-Toledo USA**

1900 Polaris Parkway Columbus, Ohio 43240 TEL. (800) 883-2171 (614) 438-4511 FAX (614) 438-4900

# Mettler-Toledo, Canada

TEL. (800) 263-6593 FAX (614) 438-4846

## Mettler-Toledo S.A., Mexico

TEL. 52 55 5547 1634 FAX (525) 541-2228

# Mettler-Toledo, Australia

Port Melbourne, Vic 3207 TEL. 61 3 9644 5710

# For all other countries: Mettler-Toledo Sales International

Switzerland TEL. +41-44-944 22 11 FAX +41-44-944 31 70

Specifications subject to change without notice.

©2006 Mettler-Toledo Inc.
METTLER TOLEDO® and SmartTouch® are registered trademarks of Mettler-Toledo Inc.

Printed in USA

RT1166.0E

Fresh Solutions for Retail

Visit for more information





**Quality certification.** Development, production, and auditing in accordance with ISO9001. Environmental management system in accordance with ISO14001.



**Tailored Services.** Our extensive service network is among the best in the world and ensures maximum availability and service life of your product.



## Conformité Européene

This label is your guarantee that our products conform to the latest guidelines.