## EZ-Clean™ Scale Terminal Systems

## NEMA 4X Packaged Scale Terminal For Hose-down Applications

Feature	Description				
Physical Dimensions	Typical Flush-M	lount Enclosure Siz	zes (Based on Reque	sted Options)	
(W x H x D)	Terminal	Height*	Width*	Depth	
	IND780, IND690	20" (508mm)	20" (508mm)	6" (152mm)	
	IND560/PANTHER®	12" (305mm)	16" (406mm)	6" (152mm)	
	PUMA®	20" (508mm)	16" (406mm)	6" (152mm)	
	* wall mounting flange increases overall height and width by 3" note: Wall mount enclosure with EZ-Clean™ controls optionally available				
Operating Temperature	-10°C to 40°C (14°F to 104°F) typical, dependent upon requested options				
Power	120 VAC or 240 VAC, 47-63 Hz, order specific				
Available Terminals	JAGXTREME, LYNX, PANTHER, PUMA				
Required Air Pressure	100 psi (6.7 bar)				
Supply Port Size	1/4" NPT				
Mounting	Flush mount into wall, mount onto wall, or onto optional pedestal (order specific)				
Options (Factory-configured)  Scale Interface	METTLER TOLEDO's analog or POWERCELL® scale interface technologies with optional PLC interface cards. Other METTLER TOLEDO scale terminals also supported				
I/O Modules  Scale Pneumatic Lift Controls  Intrinsic Safe Barriers	<ul> <li>Optional multiple scale terminals in one enclosure</li> <li>120 VAC or 240V AC I/O Modules</li> <li>Air supply fittings, pressure regulator, and internal or external key-lock manual switch for raising and lowering VERTEX® EZ-Clean scale</li> <li>ISB15000 barrier for analog 5 to 15 volt load cells</li> </ul>				
Printer Lights/Buttons/Switches	<ul> <li>Thermal printer with wash down hood</li> <li>Per customer requirements</li> </ul>				

Features	Benefits		
Compact 6" overall depth	Allows for easy flush mounting into building wall		
Optional integrated pneumatic controls	<ul> <li>Allows user to easily access scale lift controls</li> <li>Control options include internal or external key-lock providing user flexibility</li> </ul>		
Brushed stainless steel fuse welded faceplate with minimal seams	Excellent performance in "hose-down" applications where crevices and openings must be minimized to prevent fungal/bacteria growth		
Compact, integrated design	<ul> <li>Less space required</li> <li>Aesthetically pleasing</li> <li>Optional shallow mount version for 4" wall depth</li> </ul>		
Heavy duty, NEMA 4, dual latches	Provides rugged, tamper resistant, reliable door seal		
Multiple Terminal Options	Provides ability to select terminal best suited for application		

Integrates
with
VERTEX®
2158 EZClean™
Scale







Produced in a facility that is



Specifications subject to change without notice.

©2007 Mettler-Toledo, Inc.

METTLER TOLEDO® is a registered trademark of Mettler-Toledo, Inc.

Contact your local authorized METTLER TOLEDO distributor or sales office for further information.