

FIRST TIME IN INDIA

- Wash Down
- Table-top and Portable
- High Speed
- Over / Under Facility
- Inbuilt Battery Backup



Cub II IP 65 Table-top Mini-wonder

METTLER TOLEDO

Cub II - The only table-top scale for wash down weighing applications

Hygiene and speed are the most critical factors that decide efficiency and profitability in food processing and other process industries. Choice was earlier limited to either selecting a platform scale which was expensive, bulky, unhygienic and inconvenient to carry or a non-wash down table-top scale

Pioneers in wash down technology, METTLER TOLEDO brings to you for the first time in India, the only wash down table-top scale with battery backup - Cub II



Cub II has been designed to deliver trouble-free performance under tough working conditions of high moisture and low temperature levels



Best in its class protection

A unique 3-level ingress protection allows you to wash the scale along with your work station to maintain perfect hygiene

- IP 65 protection for complete scale
- IP 67 protection for PCBs and battery

Fastest response

Fastest display response time of 0.8 second enhances the speed of operation increasing productivity of your operators and plant

The check-weighing scale

Cub II is equipped with an over and under check-weighing facility which ensures that all the items are packed within specified limits

Independent operation

In-built battery back up with a powerful 6V/5Ah rechargeable battery provides uninterrupted operation for 50 hours

Ideally suited for food processing applications of:

- Frozen food
- Milk products
- Portioning, grading and packing of meat
- Seafood
- Fruits and vegetables
- Packaging of tea and dry fruits
- Packaging of pickles and spices
- Random sampling on packing lines

Other applications

- Weighing and packing of hygroscopic material such as carbon, detergent powders etc.
- Weighing in dusty environment

Unique 3-level protection

Level I



Special gasket sealing for all the joints

Level II



Dual enclosures with water-proof sealing

Level III



Damp-proof PCBs with patented glue technology

Model	Capacity (kg)	Platter size (mm)	Readability (g)	Specifications	
Cub II - 1.5	1.5	180 x 230	0.2	Ingress Protection	IP 65
Cub II - 3	3	180 x 230	0.5	Operating temperature	-10 to + 40 °C
Cub II - 6	6	180 x 230	1	Weighing units	kg / g
Cub II - 15	15	180 x 230	2	Packing dimensions	380 x 295 x 190 mm



Mettler-Toledo India Private Limited

Amar Hill, Saki Vihar Road, Powai, Mumbai - 400072

- Tel : 91 - 22 - 2857 0808 • Fax : 91 - 22 - 2857 5071
- Email : sales.mtin@mt.com • Website : www.mt.com

