Bedienungsanleitung Instruction Manual Notice d'utilisation

Transmitter Cond 7100 PA





TA-194.260-MTX02

Mettler-Toledo GmbH Process Analytics Im Hackacker 15, P.O. Box CH-8902 Urdorf

Phone: +41-1-736 22 11 Fax: +41-1-736 26 36

www.mtpro.com

Switzerland

Gewährleistung

Innerhalb von 1 Jahr ab Lieferung auftretende Mängel werden bei freier Anlieferung im Werk kostenlos behoben.

Softwareversion: 2.x

Stand Bedienungsanleitung: 06.06.2005

Warranty

Defects occurring within 1 year from delivery date shall be remedied free of charge at our plant (carriage and insurance paid by sender).

Software release: 2.x

Date of issue: June 6, 2005

Garantie

Tout défaut constaté dans les 1 an à dater de la livraison sera réparé gratuitement dans notre usine à réception franco de l'appareil.

Version logiciel: 2.x

Version du mode d'emploi : 06.06.2005



Contents

1	Information on this instruction manual E-3 Markings. E-3	7	Commissioning E-2: Checklist
2	Safety information	8	Operation E-2: Operation possibilities E-2:
3	PROFIBUS technology E-5 General E-5 Variants and basic characteristics E-5 Definitions for PROFIBUS-PA E-5 PROFIBUS-PA with the Transmitter E-6		Operation using keypad on the device E-2 Mode code E-2 Safety functions E-2 Mode indicators E-2 Configuration E-2 Calibration E-3
4	Description	9	Operating tool E-3: Measurement E-3: Diagnostics E-3: Sensocheck, Sensoface E-3: PROFIBUS-PA limit monitoring E-3:
5	Assembly E-11 Package contents and unpacking E-11 Mounting plan E-12		Error messages
6	Installation and connection E-15 Information on installation E-15 Terminal assignments E-17	10	Maintenance and Cleaning . E-4 Maintenance . E-4 Cleaning . E-4
	Overview of the Transmitter	11	Appendix E-48 Product line E-49

	Specifications
	ATEX EC-Type-Examination Certificate
	Declaration of Conformity
	FM Control Drawing
	Calibration solutions
	Glossary
12	Index E-59

1 Information on this instruction manual

1.1 Markings



The warning symbol means that the instructions given must always be followed for your own safety.

Failure to follow these instructions may result in injuries



Notes provide important information that should be strictly followed when using the device



When a key is shown, its function is explained.



When a display is shown, the corresponding information or operating instructions are provided.

Operating instructions

Each operating instruction is preceded by a dot.

Enumerations

- Each enumeration is preceded by a dash.

Model designation

For practical purposes, the Transmitter Cond 7100 PA is simply referred to as Transmitter in this instruction manual.

Trademarks

The following names are registered trademarks. For practical reasons they are shown without trademark symbol in this manual.

- Registered trademarks
 - Sensocheck[®]
 - Sensoface[®]
 - GainCheck[®]
 - InPro®

2 Safety information

2.1 Be sure to read and observe the following instructions!

The device has been designed in accordance with the state of the art and complying with the applicable safety regulations.

When operating the device, certain conditions may nevertheless be dangerous for the operator or cause damage to the device.



Whenever it is likely that protection has been impaired, the device shall be made inoperative and secured against unintended operation.

The protection is likely to be impaired if, for example:

- the device shows visible damage
- the device fails to perform the intended measurements
- after prolonged storage at temperatures above 70 °C
- after severe transport stress

Before recommissioning the device, a professional routine test in accordance with EN 61010-1 must be performed. This test should be carried out by the manufacturer.



The Transmitter is approved for installation in ATEX, FM Zone 1 with measurement in Zone 0, and FM Class I Div 1.



Before commissioning it must be proved that the intrinsic safety is maintained when connecting the device to other equipment, such as segment coupler and cable.



For hazardous-area applications, the Transmitter may only be connected to explosion-proof segment couplers, power supplies The Transmitter may be operated in accordance with the FISCO model



The stipulations of EN 60079-10: 1996 and the following must be observed for the installation



In hazardous locations the Transmitter may only be cleaned with a damp cloth to prevent electrostatic discharge.

3 PROFIBUS technology

3.1 General

PROFIBUS is a digital communication system that connects different field devices over a common cable and integrates them into a control system. In the long term, PROFIBUS will replace the 4-20 mA technology, which only supplies pure measured values.

Advantages of the PROFIBUS technology are:

- easy and cost-saving cabling
- convenient operation over a central control station
- transmission, evaluation and control of high amounts of data from field device to control station

 devices installed in hazardous locations are configured and maintained from the control station

PROFIBUS is the leading open fieldbus system in Europe. Its application range covers manufacturing, process and building automation. As open fieldbus standard to EN 50170, PROFIBUS ensures communication of different devices over one bus.

The PROFIBUS User Organization provides for further development and maintenance of the PROFIBUS technology. It combines the interests of users and manufacturers

3.2 Variants and basic characteristics

PROFIBUS determines the technical and functional characteristics of a serial bus system.

There are three PROFIBUS variants:

- PROFIBUS-FMS (FMS protocol)
 - is particularly suited for exchanging large amounts of data between control devices. It operates according to the RS 485 standard with transmission rates up to 12 MBits/sec.
- PROFIBUS-DP (decentralized peripherals)
 - is tailored for communication of automation systems and distributed peripherals. It operates according to the RS 485 standard with transmission rates up to 12 MBits/sec.
- PROFIBUS-PA (process automation)
 - is dedicated to the process industry. It permits connection of

sensors and actuators to a common bus even in hazardous locations. PROFIBUS-PA has a transmission rate of 31.25 kBits/sec

PROFIBUS distinguishes between two types of devices:

- Masters
 - control the data traffic on the bus. They send messages without external request.
- Slaves
 - are peripheral devices such as valves, drives, transmitters and analyzers. They can react acyclically to servicing, configuration and diagnostic tasks of the master. The central controller cyclically reads the measurement data with status.

3.3 Definitions for PROFIBUS-PA

The bus protocol defines type and speed of the data exchange between master and slave devices and determines the transmission

protocol of the respective PROFIBUS system.

PROFIBUS-PA permits cyclic and acyclic services.

- Cyclic services are used for transmission of measurement data and actuating commands with status information.
- Acyclic services are used for device configuration, maintenance and diagnostics during operation.

The device profile defines the device class and typical functionalities with parameters, ranges and limit values.

The FISCO model developed by the German PTB for hazardous locations permits connection of several devices to one common bus and defines permissible limits for device and cable parameters.

3.4 PROFIBUS-PA with the Transmitter




Fig. 3.1 Typical configuration of a PROFIBUS system with the Transmitter

4 Description

4.1 Intended use

The Transmitter is a PROFIBUS-PA analyzer. It is used for conductivity measurement in biotechnology, food processing, pharmaceutical and chemical industry, water/waste-water treatment, as well as for monitoring ultrapure water.

The rugged molded enclosure can be wall mounted or fixed into a control panel. It can also be mounted at a post or pipe.

The protective hood provides additional protection against direct weather exposure and mechanical damage.

The device can be easily replaced since the terminals are of a plug-in design.

4.2 Technical features

Communication between measuring point and control room is via PROFIBUS-PA. The data exchange (cyclic and acyclic) is performed

in accordance with the PROFIBUS-DP/V1 protocol.




Fig. 4.1 System functions (hardware)

4.3 Communication model

The device performance is described by function blocks according to the PNO profile for Process Control Devices.

The respective blocks contain different parameters and functions.




Fig. 4.2 Communication model Transmitter Cond 7100 PA according to the PNO Profile

4.4 Profile for Process Control Devices (extract)

Type of block	Block contents (general)	Block contents (detailed)	
Physical Block	Description of device	Measurement procedure, device configuration	
(PB)		Serial number, manufacturer name	
		Operating state (run, maintenance,)	
		Global status, diagnostics information	
Transducer	Measurement procedure with interpretation	Process variable (plain text and unit)	
Block (TB)		Number of measurement ranges (MR), start and end value of MR, active MR	
		Autorange function On/Off	
		Sampling rate of measured values	
		Uncorrected measured value with status	
Control	Control of device functions	Status of function execution of respective Transducer Blocks	
Transducer Block		Slope of sensor characteristic (cell constant)	
Transfer Trans-	Pre-processing of a measured value	Measured value pre-processing	
ducer Block		Temperature compensation	
		Selection of pre-processing function	
Transducer Limit	Limit monitoring	Block (TB) for limit setting	
Block		Threshold, effective direction, hysteresis	
		On-delay, off-delay	
		Reset behavior, reset confirmation	
		Limit status (active, not active)	

Type of block	Block contents (general)	Block contents (detailed)		
Analog Input (AI) Measured value		Currently measured value with status and scale		
Function Block		Rise time, hysteresis of Al limits		
		Upper/lower alarm limit		
		Upper/lower warning limit		
		Switchover manual/automatic operation, measured value simulation		
		Fail-safe behavior		
Discrete Input	Digital input	Switchover manual/automatic operation		
(DI)		Signal inversion		
Function Block		Fail-safe behavior		
		Limit value message/status		
Transducer	Signaling of states and events	Required maintenance, function check, errors, limit values incl. summing		
Alarm Block		Binary messages (error messages)		
Logbook Func-	Registration of states and events	Power on, power off, reset		
tion Block		State of execution (Logbook status)		
		Number of entries		
		Navigation through entries		

Tab. 4.1: Profile for Process Control Devices (function contents)

5 Assembly

5.1 Package contents and unpacking

Unpack the device carefully. Check the shipment for transport damage and completeness.

The package should contain:

- Front unit of the Transmitter
- Lower case

- This instruction manual
- Short instruction sheet
- Floppy disk with GSD file METT7533.GSD
- Bag containing small parts:





Fig. 5.1 Assembling the enclosure

- 1 Jumper (1 piece)
- Washer (1 piece): for conduit mounting: Place washer between enclosure and nut
- 3 Cable ties (3 pieces)
- 4 Hinge pin (1 piece): insertable from either side
- 5 Enclosure screws (4 pieces)
- 6 Sealing inserts(3 pieces)
- 7 Rubber reducer (1 piece)
- 8 Cable glands (3 pieces)
- 9 Filler plugs (3 pieces)
- 10 Gaskets (3 pieces)
- 11 Hexagon nuts (3 pieces)
- 12 Sealing plugs (2 pieces): for sealing in case of wall mounting

5.2 Mounting plan



- 1 Cable glands(3 pieces)
- Breakthroughs for cable gland or conduit 1/2", Ø = 21.5 mm (2 breakthroughs)
- Cable glands and conduit glands not included!
- 3 Breakthroughs for pipe mounting (4 breakthroughs)
- 4 Breakthroughs for wall mounting (2 breakthroughs)

Fig. 5.2 Mounting plan




Fig. 5.3 ZU 0275 panel-mount kit, panel cutout 138 x 138 mm (DIN 43700)

- 1 Screws (4 pieces)
- 2 Gasket (1 piece)
- 3 Panel
- 4 Span pieces (4 pieces)
- 5 Threaded sleeves (4 pieces)




Fig. 5.4 ZU 0274 pipe-mount kit

- 1 ZU 0276 protective hood (if required)
- 2 Hose clamps with worm gear drive to DIN 3017 (2 pieces)
- 3 Pipe-mount plate (1 piece)
- 4 For vertical or horizontal posts or pipes
- 5 Self-tapping screws (4 pieces)

1 Protective hood




Fig. 5.5 ZU 0276 protective hood for wall and pipe mounting

6 Installation and connection

6.1 Information on installation



Installation may only be carried out by trained experts in accordance with this instruction manual and as per applicable local and national codes.



Be sure to observe the technical specifications and input ratings.



According to the PTB FISCO model, the limits of the permissible parameter range must be observed for connection in a hazardous location.

See PROFIBUS Technical Guidelines PNO Order No. 2 091



Be sure not to notch the conductor when stripping the insulation.

For easier installation, the terminal strips are of a plug-in design. The terminals are suitable for single wires and flexible leads up to 2.5 mm² (AWG 14).

A special twisted and shielded two-wire cable (e.g. Siemens) is used as bus cable.

Division 2 wiring

The connections to the Transmitter must be installed in accordance with the National Electric Code (ANSI-NFPA 70) Division 2 hazardous (classified) location non-incendive wiring techniques.




Fig. 6.1 Information on installation

- 1 Connection leads PROFIBUS-PA
- 2 Area for placing the screwdriver to pull out the terminals
- 3 Cover for sensor terminals
- 4 Pulling out the terminal blocks using a screwdriver
- 5 Recommended stripping lengths for multi-core cables
- 6 Recommended stripping lengths for coaxial cables
- 7 Cable laying in the device

6.2 Terminal assignments





Fig. 6.2 Terminal assignments of the Transmitter

6.3 Overview of the Transmitter




- 1 Input for2- or 4-electrode sensor
- 2 Input for temperature probe
- 3 PROFIBUS-PA

Fig. 6.3 Inputs and outputs

6.4 Typical wiring

Conductivity measurement with 4-electrode sensor




Caution!

Place jumper across terminals 4 and 5! When using a sensor with Solution Ground connection (SG) or a separate SG connection, the jumper is not required!

Fig. 6.4 Conductivity measurement with 4-electrode sensor

Conductivity measurement with 2-electrode sensor (coaxial electrodes)



Caution!

Place jumpers: across terminals 1 and 2 across terminals 3 and 4 across terminals 4 and 5

Fig. 6.5 Conductivity measurement with 2-electrode sensor (coaxial electrodes)




Fig. 6.6 Conductivity measurement with Mettler-Toledo 2-electrode sensor via VP plug

Conductivity measurement with Mettler-Toledo 4-electrode sensor via VP plug




Fig. 6.7 Conductivity measurement with Mettler-Toledo 4-electrode sensor via VP plug

7 Commissioning

7.1 Checklist



Commissioning may only be carried out by trained experts.



Before commissioning the Transmitter, the following requirements must be met:

- The device must not show any damage.
- When recommissioning the device after a repair, a professional routine test in accordance with EN 61010-1 must be performed.
- It must be proved that the intrinsic safety is maintained when connecting the device to other equipment.
- It must be ensured that the device is configured in accordance with the connected peripherals.
- All connected voltage and current sources must correspond to the technical data of the device.
- The device must only be connected to explosion-proof segment couplers, power supplies ...

8 Operation

8.1 Operation possibilities




Fig. 8.1 System configuration

The device can be operated as follows:

- using the keypad on the device
- using an operating tool in the service station

8.2 Operation using keypad on the device





Fig. 8.2 Front view of the Transmitter

- 1 Display
- 2 Mode indicators
 - Measuring mode
 - Calibration mode
 - Alarm
 - PROFIBUS-PA communication
 - Configuration mode
- 3 Keypad
- 1 Coding
- 5 Rating plate

Display




- 1 Mode code entry
- 10 Not connected
- Display of measured variable
 - 11 Unit symbol
- 3 Temperature
- 12 Proceed with enter
- 4 Not connected
- 13 Bar for device status
- 5 Limit values
- 14 Manual temp indicator

6 Alarm

- 15 Hold state active
- 7 Sensocheck8 Calibration
- 16 Wait 17 Sensor data
- 9 Interval/response time
- 18 Sensoface

Fig. 8.3 Transmitter display



8.3 Mode code

After pressing meas and/or cal you can enter one of the following mode codes to access the designated mode:



conf, 0000 conf, 1200

Error Info
Configuration mode



cal, 0000 Cal Info

cal, 1015 Adjusting temp probe cal, 1100 Calibration mode

cal. 2222 Test mode

8.4 Safety functions

Sensocheck, Sensoface sensor monitoring

Sensocheck continuously monitors the sensor.

Sensocheck can be switched off.

value transfer. It runs automatically in the background at fixed intervals.



Sensoface provides information on the sensor condition.

The monitoring function alerts for significant sensor polarization or excessive cable capacitance caused by an unsuitable cable or a cable that is too long.

GainCheck manual device self-test

A display test is carried out, the software version is displayed and the memory and measured value transfer are checked. The GainCheck function ensures device operability.



Start GainCheck manual device self-test

Automatic device self-test

The automatic device self-test checks the memory and measured-

Hold state

The Hold state is a safety state that is activated in the case of interventions such as configuration and calibration. The Transmitter freezes the last valid measured value and sends a status message to the control system.



This symbol indicates that the device is in the "Hold" state.

The Hold state is activated by the following mode codes:

- Calibration
 - Mode code 1015
 - Mode code 1100
 - Mode code 2222

- Configuration

Mode code 1200

The measured value and Hold are displayed alternately

- Check whether the measured value is plausible
- enter
- · End the Hold state

After 20 sec (for measured value stabilization) the Transmitter returns to measuring mode.

8.5 Mode indicators

Measuring mode

meas

The Transmitter is in measuring mode.

Calibration mode



Calibration mode is active.

Alarm



During an error message the red alarm LED beneath the display flashes.

The alarm response time is permanently set to 10 sec.

PROFIBUS-PA communication



The Transmitter communicates via PROFI-BUS-PA and can be configured from the service station. Measured values, messages and device identification can be downloaded at any time. This allows integration in fully automatic process cycles.

Configuration mode



The Transmitter is in configuration mode.

8.6 Configuration

In the configuration mode the device parameters are set.

The following steps must be executed:



· Activate configuration



Enter mode code "1200"



Confirm entry



Welcome text 3 sec.



During configuration the Transmitter remains in the Hold state for reasons of safety.



· Select or edit parameter



· Confirm entries

All configurable parameters are shown in the "Configuration parameters" table (See Page 29).



The configuration parameters are checked during the input.



In the case of an incorrect input "Err" is displayed for approx. 3 sec. The incorrect parameters cannot be stored. Input must be repeated.



End configuration

The measured value and Hold are displayed alternately



• End the Hold state / accept configuration or



· Repeat configuration



End the Hold state



The menus are cyclically displayed.

Configuration parameters

Pictograph/display	Parameter	Selection/input	Comment	Factory setting
EELL	Sensor	2-EL 4-EL	Sensor selection: - 2-EL sensor - 4-EL sensor	2-EL
88 0 0 0.0 m5	Process variable and range	X.XXX μS / XX.XX μS / XXX.X μS / XXXX μS X.XXX mS / XX.XX mS / XXX.X mS / XXXX mS X.XXX MΩ / XX.XX MΩ / XXX.X MΩ XXX.X SAL	The selected process variable is shown in the display.	000.0 mS
	Temperature	·C	Temperature display selection	.C
	Temperature probe	Pt 100 Pt 1000 NTC 30 NTC 100	Selection of temperature probe	Pt 100
		BUS EXT	External temp during meas. [°C] Manual temp during calibration [°C]	
	Temperature compensation (Step	OFF LIN	Temp compensation selection: Linear	OFF
	omitted for SAL.)	NLF -01- FCT -02- FCT -03- FCT	Nonlinear, natural waters Ultrapure water with NaCl traces Ultrapure water with HCl traces Ultrapure water with NH ₃ traces	

Pictograph/display	Parameter	Selection/input	Comment	Factory setting
	Temperature coefficient	xx.xx %/K	Input of temperature coefficient Only with temp compensation LIN	02.00 %/K
S	Sensocheck	ON OFF	Sensor monitoring on or off	OFF
	PROFIBUS device address	0001 to 0126	Entry of PROFIBUS address of device. Be sure that the device is not communicating via PROFIBUS.	0126

Tab. 8.1: Configuration parameters

8.7 Calibration

Calibration procedures (configurable)

- Calibration by specifying the cell constant of the sensor used (See Page 31)
- Calibration with calibration solution (See Page 32)
- Adjustment of temperature probe (See Page 33)

Information on calibration

Calibration is performed by entering the cell constant or by determining the cell constant with a known calibration solution under consideration of the temperature.



All calibration procedures must be performed by trained personnel.



Incorrectly set parameters may go unnoticed, but change the measuring properties.



The calibration is directly conducted on the device.

Calibration via PROFIBUS-PA is not provided.



During calibration the Transmitter remains in the Hold state for reasons of safety.



In the case of an incorrect input "Err" is displayed for approx. 3 sec. The incorrect parameters cannot be stored. Input must be repeated.



For keypad functions see Page 25.

Calibration by input of cell constant

The following steps must be executed:



· Activate calibration



Enter mode code "1100"



Confirm entry



Welcome text 3 sec.



· Enter cell constant

The lower display shows the conductivity value.



A change in the cell constant also changes the conductivity value.



When there has not been an entry for 6 sec, the lower display alternately shows the conductivity and temperature value.



· Confirm cell constant



· End the Hold state

After 20 \sec (for measured value stabilization) the Transmitter returns to measuring mode.

Calibration with calibration solution



Be sure to use known calibration solutions and the respective temperature-corrected conductivity values (See "Calibration solutions" Page 56).



During the calibration procedure the temperature must be kept constant.

The following steps must be executed:



· Activate calibration



Enter mode code "1100"



· Confirm entry



Welcome text 3 sec



Immerse sensor in calibration solution



When there has not been an entry for 6 sec, the lower display alternately shows the conductivity and temperature value.

 Read the conductivity value corresponding to the displayed temperature from the table of the calibration solution used (See "Calibration solutions" Page 56)



 Change cell constant until the display shows the conductivity value from the table



Confirm cell constant



· End the Hold state

After 20 sec (for measured value stabilization) the Transmitter returns to measuring mode.

Adjustment of temperature probe



Especially for Pt 100 temperature probes, it is advisable to perform an adjustment.

The following steps must be executed:



· Activate calibration



Enter mode code "1015"



· Confirm entry



Welcome text 3 sec

 Measure the temperature of the process medium using an external thermometer



 Enter the determined temperature value in the main display



The lower display shows the measured temperature without adjustment. If this value is taken over for the upper display, the adjustment is without effect.



· Confirm the temperature value



· End the Hold state

After 20 sec (for measured value stabilization) the Transmitter returns to measuring mode. $\label{eq:transmitter}$

8.8 Operating tool

For parameter setting, commissioning and diagnostics of the Transmitter via PROFIBUS, we recommend operating tools such as SIMATIC-PDM Version 5 or higher.

The current device description is included.

8.9 Measurement

Measuring mode

In the measuring mode the main display shows the configured process variable and the lower display the temperature.



The Transmitter returns to measuring mode, also from configuration or calibration mode (after a relax time for measured-value stabilization, if required).

Cal Info

"Cal Info" shows the current cell constant.



Activate "Cal Info" function



Mode code



· Confirm

The current cell constant is displayed for approx. 20 sec.



End "Cal Info"

Error Info

"Error info" shows the most recent error message.



Activate "Error Info" function



Mode code



· Confirm

The error message is displayed for approx. 20 sec. After that the message will be deleted.



· End error info

9 Diagnostics

9.1 Sensocheck, Sensoface

Sensocheck continuously monitors the sensor.


Sensocheck can be switched off.



A friendly Smiley can only be displayed when Sensocheck has been activated.



Sensoface provides information on the sensor condition.





The Sensoface status does not influence the measured value display.

9.2 PROFIBUS-PA limit monitoring

The Transmitter is equipped with two limit blocks that can be separately configured for the process variables conductivity, salinity or temperature.

Configuration is only performed via the bus.

The limit conditions are transmitted cyclically.

Hysteresis, effective direction, on and off delay can be configured.



Limit value setting and output of limit messages is via the PROFIBUS-PA.



When this symbol is displayed, limit block 1 is active.



When this symbol is displayed, limit block 2 is active.

9.3 Error messages

When one of the following error messages is displayed, the device can no longer determine the measured variable correctly.

The alarm response time is permanently set to 10 sec.



During an error message the red alarm LED beneath the display flashes.



The error messages in the display are sorted according to their priority. A higher-priority message overlays a lower-priority message.

Error No.	Display (flashing) F	Problem	Possible causes
Err 01	1 17 9 _m 5	Sensor	 Wrong cell constant Conductivity ≥ 1000 mS/cm SAL > 45 ‰ Sensor connection or cable defective
Err 02	1 17 9 m5	Sensor	- Unsuitable sensor
Err 03		Temperature probe	Outside temp range Outside temp range for TC Outside temp range for TC
Err 33	*	Sensocheck	Wrong sensor Sensor defective Connecting cable too long or unsuitable Connection cable or electrode cap defective Connection terminals or electrode cap dirty
Err 98	EonF	System error	Memory error in device program Measured value transmission defective Configuration or calibration data defective Completely reconfigure and calibrate the device

Error No.	Display (flashing)	Problem	Possible causes
Err 99	FA IL	Factory settings	EEPROM or RAM defective Error in factory settings This error message normally should not occur as the data are protected from loss by multiple safety functions. Send in the device for repair and recalibration.

Tab. 9.1: Error messages

9.4 Display messages and PROFIBUS communication

User interface /	User interface / display of device Cause				Commu	nication via PF	ROFIBUS		
Display pictograph	Display message	Sensoface	LED	(see Page 37)	No. of binary message (logbook)	Analog input status	Physical Block (PB) Global status	Text of binary message (factory setting)	Logbook entry (factory setting)
FA IL	Err 99		Х	Factory settings defective	1	0000 11xx	Failure	ERR SYSTEM	Х
Conf	Err 98		Х	Configuration data defective, Gaincheck	2	0000 11xx	Failure	ERR PARAMETERS	Х
[onF	Err 98		Х	Memory error (RAM, ROM, EPROM)	3	0000 11xx	Failure	ERR MEMORY	Х
11795	Err 01		Х	Cond, sal range violation	4	0101 01xx	Failure	ERR MEAS VALUE	Х
11795	Err 02		Х	Conductance range violation	5	0100 0111 0100 1111	Failure	ERR COND VALUE	Х
	Err 03		Х	Temp range violation Temperature probe	6	0100 0111 0100 1111	Failure	ERR TEMP VALUE	Х
1	Err 33	:	Х	Sensocheck	7	0100 0111 0100 1111	Failure	CHK SENSOR	X

User interface / display of device			Cause	Commu	nication via Pf	ROFIBUS				
Display pictograph	Display message	Sensoface	LED	Comments (see Page 37)	No. of binary message (logbook)	Analog input status	Physical Block (PB) Global status	Text of binary message (factory setting)	Logbook entry	(factory setting)
• SLOPE ZERO •		<u> </u>		Cell constant	8	1010 01xx	Mainte- nance req.	CHK SLOPE	Х	
cal				Calibration	9	0100 0111 0100 1111	Function check	CAL RUNNING	Х	
conf 🏂				Configuration	10	1010 00xx	Function check	CONF RUNNING	Х	
				HOLD (Device state = Maintenance)	11	0100 0111 0100 1111	Function check	HOLD	Х	
				HI_HI_LIM FB analysis Cond/MΩ/SAL	12	1000 1110	Limit 1 Bit 1	HI_HI_LIMIT COND HI_HI_LIMIT MOCM HI_HI_LIMIT SAL		
				HI_LIM FB analysis Cond/MΩ/SAL	13	1000 1010	Limit 1 Bit 2	HI_LIMIT COND HI_LIMIT MOhm cm HI_LIMIT SAL		
				LO_LIM FB analysis Cond/MΩ/SAL	14	1000 1001	Limit 1 Bit 3	LO_LIMIT COND LO_LIMIT MOhm cm LO_LIMIT SAL		
				LO_LO_LIM FB analysis Cond/MΩ/SAL	15	1000 1101	Limit 1 Bit 4	LO_LO_LIMIT COND LO_LO_LIMIT MOCM LO_LO_LIMIT SAL		

User interface /	User interface / display of device			Cause	Commu	nication via PF	ROFIBUS			
Display pictograph	Display message	Sensoface	LED	Comments (see Page 37)	No. of binary message (logbook)	Analog input status	Physical Block (PB) Global status	Text of binary message (factory setting)	Logbook entry	(factory setting)
				HI_HI_LIM FB temperature	16	1000 1110	Limit 2 Bit 1	HI_HI_LIMIT TEMP		
				HI_LIM FB temperature	17	1000 1010	Limit 2 Bit 2	HI_LIMIT TEMP		
				LO_LIM FB temperature	18	1000 1001	Limit 2 Bit 3	LO_LIMIT TEMP		
				LO_LO_LIM FB temperature	19	1000 1101	Limit 2 Bit 4	LO_LO_LIMIT TEMP		
				Logbook empty	20		Function check	EMPTY LOGBOOK		

9.5 Diagnostics functions

Cal Info

"Cal Info" shows the current cell constant.



· Activate "Cal Info" function



Mode code



Confirm

The current cell constant is displayed for approx. 20 sec.



• End "Cal Info"

Error Info

"Error Info" shows the most recent error message.



· Activate "Error Info" function



Mode code



· Confirm

The error message is displayed for approx. 20 sec. After that the message will be deleted.



· End "Error Info"

Test mode

In the "Test Mode" you can check the equipment for correct conductivity and temperature measurement using a resistor.



Activate "Test Mode" function



Enter mode code "2222"



Confirm entry

The equivalent resistance value is shown in the main display in $k\Omega$

- Without consideration of cell constant (c = 1)
- Without TC conversion (TC = 0)



 Display in the case of a resistance value > 2 MQ.



End "Test Mode"

The device is in Hold state.

GainCheck manual device self-test

A display test is carried out, the software version is displayed and the memory and measured value transfer are checked.



Start GainCheck manual device self-test

Automatic device self-test

The automatic device self-test checks the memory and measuredvalue transfer. It runs automatically in the background at fixed intervals.

10 Maintenance and Cleaning

10.1 Maintenance

The Transmitter contains no user repairable components.

10.2 Cleaning

To remove dust, dirt and spots, the external surfaces of the Transmitter may be wiped with a soft cloth moistened with water.

A mild household cleaner may also be used if necessary.

11 Appendix

11.1 Product line

Devices

Model designation	Ref. No.
Transmitter Cond 7100 PA for hazardous- and safe-area applications	52121047

Mounting accessories

Accessories	Ref. No.
Pipe-mount kit ZU 0274	52120741
Panel-mount kit ZU 0275	52120740
Protective hood ZU 0276	52120739

11.2 Specifications

General

Manufacturer / ID	Mettler-Toledo GmbH / METT
Model designation / ID	Transmitter Cond 7100 PA / 7533

Applications

Conductivity and temperature measurement

Input

Process	Cond	Ranges	Conductivity	0.2 μS·c to 1000 mS·c ^{b)}			
variable	input	Display range ^{a)}	Conductivity	0.000 to 9.999 µS/cm			
	2-/4- electrode			00.00 to 99.99 μS/cm			
	sensors			000.0 to 999.9 μS/cm			
				0.000 to 9.999 µS/cm			
				00.00 to 99.99 μS/cm			
				000.0 to 999.9 μS/cm			
			Resistivity	0.000 to 9.999 M Ω cm			
				00.00 to 99.99 MΩ cm			
				000.0 to 999.9 MΩ cm			
			Salinity	0.0 to 45.0 ‰ (0 to 35 °C)			
	Temperature input a)	Temperature sensor ^{a)}	Pt100 / Pt1000 / NTC 30 k Ω / NTC 100 k Ω (2-wire connection, adjustable)				
		Measurement range	Pt100 / Pt1000	-20.0 to +150.0 °C / -4 to +302 °F			
			NTC 30 kΩ /NTC 100 kΩ	-20.0 to +130.0 °C / -4 to +266 °F			
		Resolution	0.1 °C / 1 °F				
		Temperature compensation (ref-	(LIN) linear characteristic	00.00 to 19.99 %/K			
		erence temp 25 °C)	(NLF) nonlinear temperature compensation for natural waters to EN 27888 (0 to 36 °C)				
			(-01-) Ultrapure water with NaCl traces (0 to 120 °C)				
			(-02-) Ultrapure water with HCI traces (0 to 120 °C)				
			(-03-) Ultrapure water with NH ₃ traces (0 to 120 °C)				

a) Configurable

b) c = cell constant

Accuracy (± 1 count)

Conductivity value	$<$ 1 % of meas. value +0.4 $\mu S \cdot c^{-a)}$
Temperature	< 0.5 K (for Pt 100 ± 1 K, for NTC: Temp. > 100 °C < 1 K)

a) c = cell constant

Monitoring function

Sensor	Sensocheck	Polarization detection
	(can be disabled)	Monitoring of cable capacitance

Sensor standardization

Standardization	Input of cell constant with simultaneous display of conductivity and temperature				
	Temperature probe adjustment				
	Adm. cell constant	0.0050 to 1.9999 cm ⁻¹			

Conditions for use

Temperature	Operation / environment	-20 to +55 °C	
	Transport / storage	-20 to +70 °C	
Electromagnetic compatibility	RFI suppression	EN 50 081-1, EN 61 326-1	
	Immunity to interference	EN 50 082-2, EN 61 326-1	
Ingress protection	Enclosure	IP65	
Explosion protection	ATEX	II 2(1) G EEx ia IIC T4, FISCO	
	FM	IS, Class I Div1, Group A, B, C, D T4 FISCO I / 1[0] / AEx ib [ia] / IIC / T4 FISCO NI, Class I Div2, Group A, B, C, D T4 NIFW	
Data retention	Parameters and calibration data	> 10 years EEPRO	OM

Construction

Dimensions	Height	144 mm			
	Width	144 mm			
	Depth	105 mm			
Weight		Approx. 1 kg	Approx. 1 kg		
Material	laterial PBT (polybutylene terephtalate)				
Color	Bluish gray	RAL 7031			
Assembly	Wall mounting				
	Post/pipe mounting	on pipe with 40 to 60 mm diameter on square post with 30 to 45 mm edge length			
	Panel mounting	Cutout to DIN 43 700			
		Sealed against panel			
Electrical connection	Cable glands	3 breakthroughs	for included cable glands		
		2 breakthroughs	for NPT 1/2" or Rigid Metallic Conduit or cable glands		

Display and user interface

Display	LC display, 7-segment	Measured value display	Conductivity value, temperature
		3 Sensoface states	Good / average / poor
		5 mode indicators	meas / cal / alarm / online / conf
	Alarm LED	Error message	
	Display range	3 1/2-digit display	
		Automatic selection (Resolution determined by selected ra	nge)
Operation	5 keys	meas / cal / up / right / enter	
Operating tool		Device description (DD) implemented in SIMATIC PDM	

Remote interface

PROFIBUS-PA communication	Digital communication by current modulation of supply current Reading of device identification, measured values, status and message Reading and writing of parameter and configuration data	
	Protocol	PROFIBUS-PA (DPV1)
	Connection	Via segment coupler to SPC, PC, PCS
	Profile	PNO directive: PROFIBUS-PA, Profile for Process Control Devices, Version 3.0
	Physical interface	To IEC 1158-2
	Address range	1 to 126, default: 126
	Supply voltage	FISCO bus supply: 9 to 17.5 V Linear barrier: 9 to 24 V
	Current consumption	< 13.2 mA
	Max. current in case of fault (FDE)	< 17.6 mA



Prüf- und Zertifizierungsstelle ZELM Ex



EC-TYPE-EXAMINATION CERTIFICATE

(Translation)

 Equipment and Protective Systems Intended for Use in Potentially Explosive Atmospheres - Directive 94/9/EC

(3) EC-TYPE-EXAMINATION CERTIFICATE Number:

ZELM 00 ATEX 0037

(4) Equipment Conductivity Transmitter type Cond 7100 PA

5) Manufacturer: Mettler Toledo GmbH

(6) Address: CH - 8902 Urdorf

(7) This equipment and any acceptable variation thereto are specified in the schedule to this certificate and the documents therein referred to.

(8) The Prüf- und Zertfürzierungsstelle ZELM Ex, notified body No. 0820 in accordance with Article of the Council Directive 94/9/EC of 23 March 1994, certifies that this equipment has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of equipment and protective systems intended for use in potentially explosive atmospheres, given in Annex II to the Directive.

The examination and test results are recorded in the confidential report ZELM Ex 0120019047.

(9) Compliance with the Essential Health and Safety Requirements has been assured by compliance with:

EN 50 014: 1997 EN 50 020: 1994

- (10) If the sign "X" is placed after the certificate number, it indicates that the equipment is subject to special conditions for safe use specified in the schedule to this certificate.
- (11) This EC-type-examination Certificate relates only to the design and construction of the specified equipment in accordance with Directive 94/9/EC. Further requirements of this Directive apply to the manufacture and supply of this equipment.
- (12) The marking of the equipment shall include the following:



II 2 (1) G EEx ia IIC T4

Zertifizierungsstelle ZELM Ex

Dipl.-Ing. Harald Zelm



Braunschweig, June 26, 2000

Sheet 1/3

EC-type-examination Certificates without signature and stamp are not valid. The certificates may only be circulate without attention. Extracts or attentions are subject to approval by the Prüf- und Zertifiserungsstelle ZELM Ex. In case of dispute, the Certains test shall prevail.

Prüf- und Zertifizierungsstelle ZELM Ex + Sieltgraben 56 + D-38124 Braunschweig



Prüf- und Zertifizierungsstelle

ZELM Ex



(13)

SCHEDULE

EC-TYPE-EXAMINATION CERTIFICATE ZELM 00 ATEX 0037 (14)

(15) Description of equipment

The Conductivity Transmitter type Cond 7100 PA is preferably used for the recognition and processing of electrochemical quantities and is equipped with an input for inductive conductivity measurements and a temperature measuring input.

The maximum permissible ambient temperature is 55 °C.

Electrical data

BUS- / Supply loop (terminals 11 and 10) type of protection Intrinsic Safety EEx ia IIC/IIB EEx ib IIC/IIB resp.

only for the connection to a certified intrinsically safe circuit (for example FISCO - supply unit) with the following maximum values:

S.,	FISCO-supply unit	linear barrier
Umm	17,5 V	24 V
lones	280 mA	200 mA
Pome	4,9 W	1,2 W

effective internal capacitance: C, s 1 nF L 5 10 µH effective internal inductance:

conductivity measuring loop (terminals 1, 2, 3, 4 and 5)

type of protection Intrinsic Safety resp. EEx ib IIC/IIB

U. = 11,8 V maximum values:

L = 145 mA P = 165 mW (trapeziodal characteristic)

effective internal capacitance: C & 5 nF The effective internal inductance is negligibly small.

	IIC	resp.	11	В
max. permissible external inductance max. permissible external capacitance	1,3 1,5		7 9,9	mH µF

IIC resp. max, permissible external inductance 1 mH 5 mH max. permissible external capacitance 350 nF 977 nF

Sheet 2/3

EC-type-examination Certificates without signature and stamp are not valid. The certificates may only be circ without attention. Extracts or attentions are subject to approval by the Prüf- und Zertifizierungsstelle ZELN in case of dispute, the German test shall prevail.

Prüf- und Zertifizierungsstelle ZELM Ex • Sielsgraben 56 • D-38124 Braunschweig



Prüf- und Zertifizierungsstelle

ZELM Ex



SCHEDULE TO EC-TYPE-EXAMINATION CERTIFICATE ZELM 00 ATEX 0037

Temperature measuring loop (terminals 7 and 8)

type of protection Intrinsic Safety EEx is IIC/IIB resp. EEx ib IIC/IIB

maximum values:

U. = 5.9 V l_o = 3,71 mA P_o = 5,5 mW (linear characteristic)

1000 mH

C, s 250 nF

effective internal capacitance: The effective internal inductance is negligibly small.

max. permissible external inductance 1000 mH max. permissible external capacitance 42,7 µF

(only valid if external inductance and external capacitance do not exist in concentrated form at the same time)

max. permissible external inductance 1 mH max. permissible external capacitance 1,85 µF 6.85 µF

(also valid if external inductance and external capacitance exist in concentrated form at the same time)

(terminal 9)

for the connection to the equipotential bonding system

References:

Connecting the equipotential bonding is absolutely required to guarantee electrostatical leakage. The BUS- / Supply loop is safely electrically isolated from the other loops up to a voltage of 60 V. The operation manual has to be considered.

- (16) Report No.
 - ZELM Ex 0120019047
- (17) Special conditions for safe use not applicable
- (18) Essential Health and Safety Requirements

met by standards

Zertifizierungsstelle ZELM Ex

Dipi.-Ing, Harald Zelm



Braunschweig, June 26, 2000

Sheet 3/3


EC-type-examination Certificates without signature and stamp are not valid. The certificates may only be circulated without alteration. Extracts or attentions are subject to approval by the PVI- and Zertificierungustele ZILM Ex. In case of dispute, the German test shall prevail.

Prüf- und Zertifizierungsstelle ZELM Ex + Sieligraben 56 + D-38124 Braunschweig

11.4 Declaration of Conformity



11.5 FM Control Drawing



11.6 Calibration solutions

Potassium chloride solutions

Temperature	Concentration a)		
[·C]	0.01 mol/l	0.1 mol/l	1 mol/l
0	0.776	7.15	65.41
5	0.896	8.22	74.14
10	1.020	9.33	83.19
15	1.147	10.48	92.52
16	1.173	10.72	94.41
17	1.199	10.95	96.31
18	1.225	11.19	98.22
19	1.251	11.43	100.14
20	1.278	11.67	102.07
21	1.305	11.91	104.00
22	1.332	12.15	105.94
23	1.359	12.39	107.89
24	1.386	12.64	109.84
25	1.413	12.88	111.80
26	1.441	13.13	113.77
27	1.468	13.37	115.74
28	1.496	13.62	
29	1.524	13.87	
30	1.552	14.12	
31	1.581	14.37	
32	1.609	14.62	
33	1.638	14.88	
34	1.667	15.13	
35	1.696	15.39	
36		15.64	
a) Data cource: V	LI Hollwood (Editor) L	Landolt D Pärnetoin	

a) Data source: K. H. Hellwege (Editor), H. Landolt, R. Börnstein: Zahlenwerte und Funktionen ..., Volume 2, Part. Volume 6

Tab. 11.1: Potassium chloride solutions, conductivity in mS/cm

Sodium chloride solutions

Temperature [*C]	Concentration Saturated a)	0.1 mol/l ^{b)}	0,01 mol/l ^{b)}
0	134.5	5.786	0.631
1	138.6	5.965	0.651
2	142.7	6.145	0.671
3	146.9	6.327	0.692
4	151.2	6.510	0.712
5	155.5	6.695	0.712
6	159.9	6.881	0.754
7	164.3	7.068	0.775
8	168.8	7.257	0.775
9	173.4	7.447	0.740
10	177.9	7.638	0.839
11	182.6	7.831	0.861
12	187.2	8.025	0.883
13	191.9	8.221	0.905
14	196.7	8.418	0.927
15	201.5	8.617	0.950
16	206.3	8.816	0.950
17	211.2	9.018	0.995
	211.2	9.018	
18			1.018
19 20	221.0	9.425	1.041
20	226.0	9.631	1.064
	231.0	9.838	1.087
22	236.1	10.047	1.111
23	241.1	10.258	1.135
24	246.2	10.469	1.159
25	251.3	10.683	1.183
26	256.5	10.898	1.207
27	261.6	11.114	1.232
28	266.9	11.332	1.256
29	272.1	11.552	1.281
30	277.4	11.773	1.306
31	282.7	11.995	1.331
32	288.0	12.220	1.357
33	293.3	12.445	1.382
34	298.7	12.673	1.408
35	304.1	12.902	1.434
36	309.5	13.132	1.460
		III III D. D	

a) Data source: K. H. Hellwege (Editor), H. Landolt, R. Börnstein: Zahlenwerte und Funktionen ..., Volume 2, Part. Volume 6

b) Data source: Test solutions calculated according to DIN IEC 746-3

Tab. 11.2: Sodium chloride solutions, conductivity in mS/cm

11.7 Glossary

2-electrode sensor

Conductivity sensor with two electrodes. Suitable for measuring low conductivity values.

4-electrode sensor

Conductivity sensor with four (2 current and 2 voltage) electrodes. Suitable for measuring high conductivity values.

Conductance

Conductance G [S] =1 / R $[\Omega]$

Conductivity

Conductivity κ [S/cm] = G [S] \cdot c [1/cm]

Conductivity sensor

Either 2- or 4-electrode sensors can be connected. The cell constant of the sensor in use must be entered or be determined using a calibration solution taking account for the temperature. A special device variant is provided for electrodeless sensors.

FISCO Model (Fieldbus Intrinsically Safe Concept)

Permits connection of several devices to a common bus line and defines limit values for device and cable parameters. This model developed by the German PTB assumes that only one "active" device, i.e. the bus supply is connected to the field bus. All other devices are "passive" with regard to the power supply into the bus. Within the defined limits, the line characteristics have no influence on the intrinsic safety.

GSD file (device database file)

Contains the communication features of slave devices. During commissioning it is loaded in the process control system.

PROFIBUS-DP (decentralized peripherals)

Standardized specification (EN 50 170) of an open fieldbus system for binary and analog signals of sensors and actuators. It has been designed for high-speed data exchange at the device level.

PROFIBUS-PA (process automation)

Open fieldbus standard for process automation. It makes use of the transmission technology to IEC 1158-2 approved for operation in hazardous locations, which at the same time allows the field devices to be powered over the bus.

SIMATIC-PDM

Tool developed by Siemens for projecting, configuring, commissioning and diagnostic of smart process analyzers. The Transmitter device description (DD) is implemented in the SIMATIC-PDM

Temperature coefficient

With temperature compensation activated, the measured value is calculated to the value at the reference temperature using the temperature coefficient.

Temperature compensation

Calculates the measured conductivity value for a reference temperature.

12 Index

Transmitter, E-47

A	Conductivity measurement
Accuracy, E-47	InPro 7000 sensor, E-18
Adjusting temp probe, E-33	InPro 7001/7002/7003 sensor, E-19
Analog Input (AI) Function Block, E-10	InPro 7100/7104 sensor, E-20
Applications, E-45 Assembly	InPro 7100-25/7104-25 sensor, E-21
Enclosure, E-11 Pipe-mount kit (ZU 0274), E-13 Transmitter, E-12 ZU 0275 panel-mount kit, E-13 ZU 0276 protective hood, E-14	Configuration, E-28 Configuration parameters, E-29 Connecting lines, E-16 Construction Transmitter, E-48 Control Transducer Block, E-9
С	D
Cal Info, E-35, E-42	Declaration of Conformity, E-53
Calibration, E-31	Device description, E-7
Adjusting temp probe, E-33	Device self-test
Input of cell constant, E-31	Automatic, E-26, E-43
Overview, E-31	Manual, E-26, E-43
With calibration solution, E-32	Diagnostics functions, E-42
Calibration solutions	Discrete Input (DI) Function Block, E-10
Potassium chloride, E-56	Display, E-25
Sodium chloride, E-56	Display messages and PROFIBUS communication, E-39
Cell constant, calibration, E-31	Division 2 wiring, E-15
Certificate of Conformity, E-50 Cleaning of device, E-44 Commissioning, E-22	E Error Info, E-35, E-42 Error message, E-37
Conditions for use	

F	N
FISCO model, E-4, E-6, E-15, E-57	Notes
FM Control Drawing, E-55	Calibration, E-31
	Installation, E-15
G GainCheck, E-26, E-43	Safety, E-4
Galifette, E-20, E-43	This instruction manual, E-3
Н	
Hold state, E-27	0
	Operating tool, E-35
Installation E 15	Operation possibilities, E-23
Installation, E-15 Intended use, E-7	P
Interfaced use, L-7	Packing list, E-11
K	Physical Block (PB), E-9
Keypad functions, E-25	Pipe-mount kit (ZU 0274), E-13
	Process variable
L Limit monitoring	Configuring, E-29
PROFIBUS-PA, E-36	Product line
·	Devices, E-45
Logbook, E-10 Logbook Function Block, E-10	Mounting accessories, E-45
LOGDOOK FUNCTION BLOCK, E-10	PROFIBUS technology, E-5
M	PROFIBUS, variants, E-5
Maintenance of device, E-44	PROFIBUS-PA
Measurement, E-35	Definitions, E-5
Measuring mode, E-35	Limit monitoring, E-36
Mode code, E-26, E-63	Limit monitoring, E-30
Mode indicators, E-27	S
Mounting plan, E-12	Safety functions, E-26
	Safety information, E-4
	Sensocheck, E-36
	On/off, E-30

Sensoface, E-36 Sensor monitoring, E-26 Sensor standardization, E-47 Specifications Transmitter, E-45 Stripping lengths, E-16 Т Technical features. E-7 Temp probe adjustment, E-33 Temperature compensation Configuring, E-29 Terminal assignments, E-17 Test mode. E-43 Transducer Block (TB), E-9 Transducer Limit Block, E-9 Transfer Transducer Block, E-9 Transmitter, overview, E-17 Type Examination Certificate, E-50 Unpacking, E-11 User interface, E-24 W Wiring examples, E-18 Ζ ZU 0275 panel-mount kit, E-13

ZU 0276 protective hood, E-14

Mode Codes





cal, 0000 Cal Info
cal, 1015 Temp probe adjustment
cal, 1100 Calibration mode
cal, 2222 Test mode

BR Mettler-Toledo Ind. e Com. Ltda..

Alameda Araguaia, 451 - Alphaville BR - 06455-000 Barueri / SP, Brazil Phone +55 11 4166 74 00 Fax +55 11 4166 74 01

CH Mettler-Toledo (Schweiz) AG,

Im Langacher, CH-8606 Greifensee, Switzerland Phone +41 44 944 45 45 Fax +41 44 944 45 10

Mettler-Toledo GmbH, Prozeßanalytik, D

Ockerwea 3. D-35396 Gießen, Germany Phone +49 641 507-333 Fax +49 641 507-397

F Mettler-Toledo Analyse Industrielle Sàrl,

30 Bld. de Douaumont. BP 949. F-75829 Paris Cedex 17, France Phone +33 1 47 37 06 00 Fax +33 1 47 37 46 26

USA Mettler-Toledo Ingold, Inc.,

36 Middlesex Turnpike, USA - Bedford, MA 01730, USA Phone +1 781 301-88 00 Fax +1 781 271-06 81



