



**Model 706**

Semi-Automatic

Prepack System

## Automatic Weighing and Labeling for Hand Wrapping Operations

**METTLER TOLEDO**

# Makes Your Hand Wrap Operation Faster, More Efficient

- ☐ Automatic weighing and labeling
- ☐ Generates labels with graphics, recipes, cooking instructions, etc.
- ☐ Touchscreen is easy to learn and use...saving time and training
- ☐ Prints Day-glo labels for increased merchandising

The 706 Auto-Labeler® lets you add components to make your hand wrapping operation more productive for both regular and peak periods. Add the SmartTouch Prepack System, Model 661 Handwraps, and Model 623 Sealing Belt Conveyor, and you have an efficient, space-saving semi-automatic system.



## Model 706 Auto-Labeler

The 706 Auto-Labeler automatically indexes and positions trays for weight/price labels. Packages are conveyed one at a time onto the scale conveyor for weighing and then to the labeling position for applying the price label.

- Consistent price label placement for all tray sizes
- You can easily add an additional printer to print Day-glo merchandising labels
- Easy access to scale for manual weighing of large items

## SmartTouch Prepack System

The SmartTouch Prepack System provides the software control, weighing, and printing capabilities for the 706 Semi-auto system.

- 8361 SmartTouch is an easy-to-use touch screen controller with multiple networking options, including Ethernet TCP/IP
- 317 Price Label Printer provides standard text and graphics printing and large label capacity
- 8270 Scale provides fast, accurate weighing

## Specifications

Operating Temperature: 41°F to 104°F (5°C to 40°C), 10-90% humidity, non-condensing  
Electrical: 115 VAC, 60 Hz, 2kVA, 230 VAC optional  
Scale Capacity: 50lb x 0.01lb (20kg x 0.005kg)

## Mettler-Toledo, Inc. Scales & Systems

**USA**  
1900 Polaris Parkway  
Columbus, Ohio 43240  
TEL. (800) 786-0038  
FAX (614) 438-4783

## Mettler-Toledo Inc.

**Canada**  
TEL. (800) 263-6593  
FAX (905) 681-1511

## Mettler-Toledo Ltd.

**Australia**  
TEL. (61) 3 9646 4551  
FAX (61) 3 9645 3935

## International Operations

**Americas**  
TEL. (614) 438-4801  
FAX (614) 438-4755

**Europe, Africa, Near East  
and Pacific Rim**  
TEL. (41) 1 944 22 11  
FAX (41) 1 9444 30 60

**Internet**  
www.mt.com

Specifications subject to change without notice  
©1999 Mettler-Toledo, Inc.

METTLER TOLEDO® and SmartTouch® are  
trademarks of Mettler-Toledo, Inc.

Printed on recycled paper and is recyclable.

Printed in USA.  
7.5M1099  
RT1061.0E

## Model 661 Handwrap Station and Model 623 Sealing Belt Conveyor

The Models 661 and 623 work together to provide the hand wrapping, film sealing, and tray indexing function.

- 661 is available with either 2 or 3 film roll support
- A second 661 station can be added for higher throughput during peak periods
- 623 Sealing Belt provides uniform heat control for superior film seals



8361 Controller