

## **Operator friendly weighing**

Eliminates delays and keeps traffic moving



# Shipping and receiving made easy no matter how you weigh your vehicles

- Weigh and store your inbound/outbound shipments or deliveries
- Automatically determine what you receive or ship
- IND310 supports stored, temporary and transient tare weights

#### Powerful - weighing functions

The IND310 includes an efficient database that stores temporary or permanent vehicle weights. User defined information can be tracked in configurable tables.


## Flexible – print custom label formats

Print your existing ticket format using a customised template with both inbound and outbound transactions. You also have the freedom to define your management reports independently from your transaction document and include the data that you want in your exact format.

## Efficient – customise to save time and money

Customise the graphic display to your needs with configurable shortcut keys. Features can be enabled or disabled to suit specific transaction requirements. Automatic ID generation and quick start options speed up transactions.

#### Reliable – 24/7



#### **Application support**

The IND310 comes with a PC application called PCTools. PCTools allows the user to backup and restore terminal configuration, to remotely configure the IND310, or to export and import database tables via Microsoft® Excel.

#### **Accurate weighing**

The IND310 supports up to two scales, either analogue or POWER-CELL. Transactions on one scale are seamlessly linked to transactions on the other scale.





#### Easy to read display

Shows only the data you need and eliminates operator errors.

#### Ten configurable soft keys

Quickly access the functions you want/need.

#### Fast database search

Quickly find records in your database.

#### Supports up to two printers

Print inbound/outbound transaction tickets and management reports.

#### Alibi function (Europe)

Minimum of three months.

#### Multi-lingual

Supports English, German, French, Spanish, Italian....

#### **USB** memory stick

For easy backup and restore of your database and configuration data.

#### **Indexed** weighing

Allows you to link database items such as driver, vehicle and product to reduce operator keystrokes.


#### Four application keys

Allows quick access to database.

- Permanent trucks
- Temporary trucks
- Transactions
- User defined tables

#### User oriented view angle

Easily adjust the viewing angle with the base bracket and "skewer" quick release clamp.





#### Technical data

#### **IND310**

### Vehicle Weighing Terminal



Enclosure type	Heavy- duty stainless steel with quick-adjust wall or desk mount stand
Environmental protection	Inside/outside (washable) IP69K -10°C to +40°C (14°F to 104°F) approved20°C to +50°C operational. 10 to 95% humidity, non-condensing.
Power	Universal internal AC power supply 87 to 264 VAC, 49 to 61Hz
Graphic display	Bright 1/4 VGA LCD (320x240 pixels) with backlight
Analogue load cells (per channel)	$8~(350\Omega)$ to 22 METTLER TOLEDO Model 0782
Weight display	Clear and adjustable up to 24mm (0.9in) character height
Number of scales	Up to two platforms
Scale Types	Analogue, POWERCELL®, and POWERCELL® MTX load cells
Number of load cells	Eight $350\Omega$ analogue load cells per channel, maximum of two channels.  Ten POWERCELL® or POWERCELL® MTX load cells (24 with optional external power supply).
External keyboard	Terminal supports optional external keyboard via PS2 connector
Communications	Two serial ports: RS-232, 20 mA CL, RS-422, RS-485, TCP/IP 10Base-T Ethernet
Dimensions (WxDxH)	300mm x 270mm x 190mm 11.8in x 10.6in x 7.5in
Net / Shipping Weight	5.5kg / 8.0kg, 12lb / 17lb
Approvals	UL 60950, Class III/IIIL/IIIHD NTEP CC04-032, CE,TÜV, EN45501,EN55022,89/336/EU, TC6498, T2206, T2391, OIML R76, AM5539

#### Mettler-Toledo, Inc.

1900 Polaris Parkway, Columbus, OH 43240 Tel. (800) 786-0038 / (614) 438-4511 Fax (614) 438 4900

#### Mettler-Toledo GmbH

Industrial CH-8606 Greifensee Switzerland

Tel. +41 44 944 2211 Fax. +41 44 944 3060

METTLER TOLEDO® is a registered trademark of Mettler-Toledo Inc. All other brand or product names are trademarks of their respective companies.

Subject to technical changes © 2006 Mettler-Toledo Inc. IN03444.0EE

44099736

#### www.mt.com

Visit for more information





**Quality certification.** Development, production, and auditing in accordance with ISO9001. Environmental management system in accordance with ISO14001.



**Tailored Services.** Our extensive service network is among the best in the world and ensures maximum availability and service life of your product.



#### Conformité Européene

This label is your guarantee that our products conform to the latest guidelines.