



General Purpose Terminal

Model	JAGXTREME (JXGA)
Physical Dimensions W x D x H	255 x 270 x 200 mm/10.05 x 8.03 x 5.6 in.
Operating Temperature	-10° C to 45° C (14° F to 113° F); 10 to 95% humidity, non-condensing
Power	85 to 264 VAC, 47-63 Hz, auto-sensing (000 finish code) 190 to 264 VAC 47-63 Hz (other finish codes)
Environmental Protection	NEMA 4
Display	Upper: 7-digit, 7-segment vacuum fluorescent, 13 mm/0.5 in. high Lower: 16-characters, 5 x 7 dot matrix vacuum fluorescent, 6 mm/0.25 in. high
Controller PCB	Ethernet, 10BASE-T 4-discrete inputs continuous 4-discrete outputs continuous COM1: RS-232 or 20mA current loop active transmit/passive receive COM2: RS-232 or RS-422/RS-485 (DigiTOL® scale) PS/2 type QWERTY keyboard connection
Approvals	NTEP CoC #94-096 Class III/IIIL, 10,000d; OIML NMi TC2618, AM-5041 (Canada); cUL, UL

Options:

- Analog, DigiTOL[®], POWERCELL[®], and High Precision scale interfaces
 PROFIBUS[®] interface, Allen-Bradley[®] RIO option, ControlNet/Ethernet/IP, and MODBUS PLUS[®]
- Reduced excitation analog scale interface
- Multifunction I/O interface card—provides two additional serial ports, 8 discrete inputs, 8 discrete outputs
- Analog output—4-20 mA, 0-10 VDC, 2 separate channels

Features Benefits Panel Mount Enclosure ■ Simple mounting through rectangular cutout ■ 10BASE-T (RJ-45) port standard (TCP/IP, SMTP, HTTP, FTP, PPP **Ethernet Port** True web-based server embedded for configuration and diagnostics Upload and download reports, configurations, JagBASIC® programs via the internet Alphanumeric Keyboard Entry Intuitive setup and custom operator prompting Five Printer Templates ■ Program custom serial outputs to print exactly what is required ■ Interface multiple serial peripheral devices for data input and Two Serial Ports output-fully configurable Four Scale Operation ■ Simultaneously supports two scale platforms in any combination of the following technologies (Analog, DigiTOL POWERCELL, DigiTOL J-box/Bench, IDNET). If the technologies are all analog or POWERCELL, the terminal can be configured to support four scale platforms. Self-Diagnostics ■ Quick, simple troubleshooting saves installation, start-up, and troubleshooting time Stored Tare and Zero Values Accurate restart of system after power loss with no need to empty scale More Than 300 A/Ds Per ■ Quick weight response resulting in more accurate weights in Second automated weighing systems Extended JagBASIC® Provides a quick and easy method to provide custom programming. Additional programming and data memory are now standard Programming Language TraxDSP™ Filtering Reduces vibration effects to give a stable, accurate weight Includes ultra-quiet analog front end, a proprietary high speed/high resolution A/D and dedicated 16-bit processor for serial processing TraxEMT™ Maintenance ■ Embedded Maintenance Technician—Maintenance planning, condition monitoring, calibration checking, fault recognition and recovery; ISO compliance Allen-Bradley[®] Remote I/O Option MODBUS[®] PLUS Direct connection to PLC, DCS, and PC-based control, HMI and SCADA systems Interface PROFIBUS® DP Slave Interface

Contact your local METTLER TOLEDO authorized distributor or sales office for further information.

Powerful, Dependable, **Flexible**













